


C9150-2 / 3 Control

for Series 9200 4-Wing 2-way Security Revolving Door

SETUP INSTRUCTIONS & TROUBLESHOOTING

To be used with G918 Installation Instructions



H915, JAN 2003

Horton
AUTOMATICS

OVERVIEW OF THE C9150 2-WAY SECURITY REVOLVING DOOR CONTROL

This manual contains very detailed instructions for successful setup and adjustment of the C9150 control. All wiring and initial run of the door can be accomplished by following the directions in sections 1 through 14.2. The remainder of the manual contains reference material for options and features that may not be required in all applications.

The concise table of contents will be useful to find the pertinent section of the instructions required for each application. The C9150 control offers greater flexibility than any revolver control offered before. The operation of the door can now be changed with the keyswitch or remote control. Previously, these functions were changed by changing the firmware (eprom chip). The C9150 has expansion slots for additional input, output or specialized cards that can be added to expand the capabilities of this versatile control.

THIS MANUAL CONTAINS THE FOLLOWING SECTIONS:

BASIC SETUP A step by step outline of the wiring, setup and testing of each part to be installed such as motor and brake, mats, nosing etc.

The sections below give detailed instructions on setting up the functions that are accessed by the keyswitch, remote control and the control itself. The remote may be password protected if desired.

DIAGNOSTICS: Used to setup and maintain the revolving door such as...

- Calculating the speed of the door in RPM's
- Testing the voice module.
- Global relearn which sets the safety sensitivity to an optimum level.
- Checking motor and brake voltage and current.

MODE: Defines how the door will be used

- Totally secure, card reader access for entry and exit.
- Card reader entry with free exit.
- Motion detector activation in and out
- Freewheel mode.

PARAMETERS: Cover such functions as...

- Door speed
- Time delays
- Reaction to, and force required for safety stops.
- Adjust card request storage, safety stops before idle and many other variables.

INSTRUCTIONS TO INSTALLER

- This door is to be installed by an experienced installer, trained by Horton Automatics.
- To ensure safe and proper operation, the door must be installed and adjusted to conform to Horton Automatics recommendations and all code requirements.
- If there are any questions about these instructions, call Horton Automatics Technical Service (1-800-531-3111).

INFORMATION TO BE PROVIDED BY THE DISTRIBUTOR TO THE OWNER

- After installation, instruct the owner on the safe operation of the door.
- Present the Owners Manual M910 (security) and explain how to perform the daily safety check.
- Location of power on / off switch.
- Necessary warnings not covered in these general instructions.
- Date equipment shipped from Horton Automatics.
- Date equipment placed in service.
- Horton Automatics' work order number for warranty reference.
- Equipment type.
- Accessories included.
- Phone number of local distributor to call regarding problems or request for service.
- **Give caution** to owner: If a potentially hazardous situation is suspected, the door should be taken out of automatic service until a professional inspection is made and the problem is corrected.


GENERAL REQUIREMENTS

- Power: (Switchable on the control) 120 or 240 service to each unit.
- For remote switch locations, routing of low voltage class II wiring to the operator controls will be required.
- Remote switch locations should be predetermined and wired before installation begins.


CONTENTS

REFERENCE (for basic setup)	
A. C9150 Control and power supply.....	H915.1
B. Control connections.....	H915.2
BASIC SETUP	
1. Basic setup (wiring motor, brake and encoder).....	H915.3
2. Basic setup (wiring reference switches).....	H915.4
3. Basic setup (wiring slip ring assembly and magnetic breakout).....	H915.5
4. Basic setup (wiring emergency stop switch, fire alarm, LCP and key switch).....	H915.6
TESTING SETUP	
5. Basic setup (introduction to diagnostics).....	H915.7
6. Basic setup (checking motor and brake current).....	H915.8
7. Basic setup (setup run).....	H915.9
8. Basic setup (setup run).....	H915.10
BASIC SETUP	
9. Basic setup (mat installation).....	H915.11
9.1 Basic setup (mat installation).....	H915.12
10. Basic setup (wiring card readers and speakers).....	H915.13
11. Basic setup (routing wires & mounting reader brackets).....	H915.14
11.1 Basic setup (wiring reader brackets).....	H915.15
12. Basic setup (wiring motion detectors and lights).....	H915.16
13. Basic setup (nosing wiring).....	H915.17
TESTING SETUP	
14. Basic setup (testing) walk test & un-authorized entry.....	H915.18
14.1 Basic setup (testing) safety stop & idle test.....	H915.19
14.2 Basic setup (testing) motion detectors.....	H915.20
REFERENCE CHARTS (for setup)	
DIAGNOSTICS	
15. Diagnostics chart 1 (check power supply • check door speed).....	H915.21
16. Diagnostics chart 2 (check motor & brake voltage & current).....	H915.22
17. Diagnostics chart 3 (encoder & input test).....	H915.23
18. Diagnostics chart 4 (voice & check statistics).....	H915.24
19. Diagnostics chart 5 (reserved diagnostics & learn safety limits).....	H915.25
20. Diagnostics chart 6 (complete setup).....	H915.26
MODES	
21. Door modes (modes 0 thru 11 for std operating software. 12 thru 15 for x position).....	H915.27
21.1 Door operating modes (using the ir remote).....	H915.28
PARAMETERS	
22. Parameter chart 1 (Speed • normal • reduced • reverse • reserved).....	H915.29
23. Parameter chart 2 (safety sensing & safety stop time).....	H915.30
24. Parameter chart 3 (inactive timeout & security pass timeout).....	H915.31
25. Parameter chart 4 (idle mode timeout • entry/exit alert time • verify contact time).....	H915.32
26. Parameter chart 5 (reserved time • motec delay time • safety stops to idle).....	H915.33
27. Parameter chart 6 (max entry • backup warnings • network address • reserved).....	H915.34
28. Parameter chart 7 (k2,k3 & k4 mapping • door mode).....	H915.35
29. Parameter chart 8 (hardwired mode A & mode B • mode 0 thru 15 permitted).....	H915.36
30. Parameter chart 9 (remote mode slct • slows to opt x mode • clrs mats ea cycle).....	H915.37
31. Parameter chart 10 (fixed power-up mode • locked in auto mode • reserved).....	H915.38
QUICK REFERENCE CHARTS	
32. Parameter quick reference chart.....	H915.39
33. Diagnostics quick reference chart.....	H915.40
34. Error codes.....	H915.40

A. C9150 CONTROL AND POWER SUPPLY



B. CONTROL CONNECTIONS



1. BASIC SETUP(wiring motor,brake and encoder


NOTE:

If the door runs backwards, when tested in section 6:

- Check that the gear drive is not upside down. "Top" should be stamped on the "up" side. The gear drive may be turned over to the correct position

OR...


- Reverse the black and white leads at the CN 1 connection.
- If an encoder error occurs reverse leads 2 and 3 on the encoder.




Brake, motor and encoder connections are factory installed. Illustrations are for reference only

Motor (Red) ==> Wht - To the power
Motor (Blk) ==> Blk - supply

Brake and motor connection




NOTE
Route all wiring through the 1 1/2" strain relief




2nd Step Brake and motor connection

C385-1-1
6 foot (1829mm)
power cord




NOTE:
DO NOT PLUG IN UNTIL
LATER (SECTION 6)


1st Step Check power supply for proper voltage setting




3rd Step Encoder connection at the control board




2. BASIC SETUP (wiring reference switch)




INDICATOR SETUP FOR 4-WING



INDICATOR SETUP FOR 3-WING




3. BASIC SETUP (wiring the slip ring assembly and magnetic breakout)



4. BASIC SETUP (wiring emergency stop switch, fire alarm, LCP and key switch)

TURN BREAKER OFF
BEFORE CONNECTING WIRING




H915.6

5. BASIC SETUP (introduction to diagnostics)

Before proceeding 3 diagnostics should be performed. Spot check of motor and brake function to insure proper operation and then a setup run. The following is an outline of performing those diagnostics.

- These diagnostics may be performed using the IR control and the LCP (Local Control Panel) or the MCP (Main Control Panel).
- The MCP will provide more information and can be used for reference even when using the remote / LCP.



-The door must be inactive (at rest)


Accessing the diagnostics from the infrared control.

- Point the IR remote at the LCP and press unlock.
- The red LED on the LCP display will flash - indicating the signal is being received.
- If the control was previously locked with a password, the LCP will show "L" to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.
- If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as P.1

-Press "SU" diagnostics will appear

Accessing the diagnostics from the control itself.

- Press and hold the DOWN button while briefly pressing RESET.
- The version number will display
- If the control is locked with a password it must be unlocked with the IR remote.
- Diagnostics/Setup will display
- Release the DOWN button



GO TO NEXT PAGE TO CHECK MOTOR AND BRAKE CURRENT

6. BASIC SETUP (checking motor and brake current)

PLUG IN CN1 (motor and brake connection) as shown in basic setup 1.
If the door runs backwards see section 1.

Accessing the diagnostics from the infrared control.

Accessing the diagnostics from the control itself.

CAUTION: DOOR WILL MOVE AT SPEED SET IN PARAMETER 1 (default 60 volts)

CHECK MOTOR CURRENT

•Press 3 or "+" up "-" down until 3 is displayed

•Press "7"


•Displays motor amperage

•Useful for detecting mechanical binds
•checking overall performance of the door's mechanics.

MOTOR CURRENT SHOULD BE .50A TO 1.0A.

Higher than normal current suggests a mechanical bind or "rarely" an electrical problem

•Press SU again to exit



CHECK BRAKE CURRENT (This test checks the brake (lock) mechanically and electrically)

•Press 5 or "+" up "-" down until 5 is displayed

•Press "7"


•Brake current is displayed.

BRAKE CURRENT SHOULD BE 180ma TO 200ma.

Low brake current indicates an open connection. Check motor / brake connection at CN1 section 1 basic setup.

Push the door to make sure the brake is physically locked.

•Press SU again to exit



GO TO NEXT PAGE

7. BASIC SETUP (setup run)

Before installing any additional devices, a setup run should be performed. The setup run sets factory default settings to all parameters, zeros all counters and sets safety sensitivity settings.


Accessing the diagnostics from the infrared control.

Accessing the diagnostics from the main control panel.

COMPLETE SETUP

CAUTION: The door will move on its own when this routine is initiated! use extreme caution to avoid entrapment.

This diagnostics allows a complete control setup to be performed. This diagnostic can be the most **DESTRUCTIVE** if it is performed accidentally. This diagnostic should always be performed when initially installing a door and **never** be performed without good reason otherwise.



8. BASIC SETUP (setup run)

Accessing the diagnostics from the infrared control.

Accessing the diagnostics from the main control panel.

COMPLETE SETUP (CONT)

REVERSE SPEED CURRENT

•The door rotates through four quarterpoints at reverse speed to determine the maximum current

0.52

STARTUP CURRENT

•The door rotates through one quadrant

0.98

Version number is displayed

04--


•Press the lock key

•Press the RESET button.

RESET

THIS CONCLUDES THE BASIC SETUP RUN


NOTE:
Disconnect CM1 (motor & brake) so that the auxiliary equipment can be connected and tested without the danger of the door rotating and causing injury or someone becoming entrapped by the brake (lock).



GO TO THE NEXT PAGE TO COMPLETE THE WIRING

9. BASIC SETUP (mat installation)

TURN BREAKER OFF BEFORE CONNECTING WIRING




1st Step

If the hole for the mat wire has not been pre-drilled - locate approx as shown. Drill a 3/4" hole.


2nd Step

Lay mat in the door and mark locations of wires. If not already done, cut a 3/8" high x 1" notch for wire access on all 4 entry posts.



NOTE:

Mats should be installed before the wings.






4th Step

Position the active mat under the spider first then against the bottom drum rail. See floor plan for proper placement.

3rd Step

Drop a small "fish" chain down through the vertical throat rail and out through the slot at the bottom. Attach the chain to the mat wire. While feeding the wire in from the bottom pull the wire into the canopy (see plan)




NOTE:

On a segmented door access is located above the ceiling at the throat rail

GO TO NEXT PAGE

9.1. BASIC SETUP (mat installation)




10. BASIC SETUP (wiring card readers and speakers)

TURN BREAKER OFF BEFORE CONNECTING WIRING

Improper adjustment of contrast can cause the display to look blank

Contrast Adjust volume and contrast to 9:00

Limit Adjust limit fully counter clockwise



1st Step
Connect the speaker and set the Limit, Contrast and Volume as shown. Go to diagnostics 8 to test voices.

Dry momentary contact .5 - 1 sec duration from card reader system



Card reader system by others

2nd Step

For test purposes:


- Connect a 2 conductor (scrap) wire to 1 & 2 of CN10 and temporarily run to the ENTRY side of the door.
- Connect 3&4 of CN10 to the EXIT side of the door.




3rd Step

Turn power on and test as follows:

- Close the connection between 1 & 2 on CN 10
D16 will light
- Close the connection between 3 & 4 on CN 10
D17 will light




Wiring and card readers by others




11. BASIC SETUP (routing wires & mounting reader brackets)

TURN BREAKER OFF BEFORE CONNECTING WIRING




11.1 BASIC SETUP (wiring reader brackets)

TURN BREAKER OFF
BEFORE CONNECTING WIRING



12. BASIC SETUP (wiring motion detectors and lights)

TURN BREAKER OFF
BEFORE CONNECTING WIRING




13. BASIC SETUP (nosing wiring)

TURN BREAKER OFF
BEFORE CONNECTING WIRING

5th Step TEST THE NOSINGS

- Turn the power on.
- Push each leading nosing LED D20 will come on.
- Push each trailing nosing LED D22 will come on



1st Step

Interface board is supplied with the control accessories. Mount to the gear drive support tubes with #6 SMS (drill 3/32" pilot hole)

2nd Step

Route safety edge wiring to control nosing interface board mounted on geartrain support tubes

3rd Step

Make connections at nosing interface board.



4th Step

Connect harness from CN11 to interface board


E6238 Nosing harness is supplied with the control accessories. Wiring color code is shown for reference only.

E6024 Nosing interface board is supplied with the control accessories.

NOTE:
2 WIRE NOSING IS SHOWN
DO NOT CUT JUMPERS IF
WIRING LOOKS LIKE THIS



Nosing wires should be pulled into the canopy during drum and canopy assembly



14. BASIC SETUP (testing)

The following tests are designed to check all inputs and outputs without regard to mode. The tests are conducted in mode 2 (card/card +) and mode 11 (molec/molec), if molecs are used. ATTENTION "X" logic users, all tests are conducted in the "+" position - return to the "X" position after the test is complete.

Plug in CN1 (motor and brake) and turn the breaker on.

WALK TEST (mode 2)

(If MCP does not read mode 2 ready... see SEC.21)

Card in may be simulated by closing the contacts between 3 & 4 on CN10

D17 lights on CN10


System is waiting for contact with the mat

Step on the mat-D11 Exit mat lights up and motor starts to run

Walk through - the door will seek X and then +reference

If the mat is not cleared in the time required a count down begins to a security violation

Exit from the revolver and the system returns to inactive status



UN-AUTHORIZED ENTRY (mode 2)

(If MCP does not read mode 2 ready... see SEC.21)

Card in may be simulated by closing the contacts between 3 & 4 on CN10

D17 lights on CN10

System is waiting for contact with the mat

Step on the mat-D11 Exit mat lights up and motor starts to run


If an un-authorized enter is attempted from the other side the door will stop and announce a security violation

The door will then start to backup after the announcement is complete

The mats must be cleared on both sides

The door may be re-entered from the authorized side

The authorized entry may proceed through the door



14.1. BASIC SETUP (testing)

The following tests are designed to check all inputs and outputs. The tests are conducted in mode 2 (card/card +) and mode 11 (motec/motec), if motecs are used. Plug in CN1 (motor and brake) and turn the breaker on.

SAFETY STOP (mode 2)

(If MCP does not read mode 2 ready... see SEC.21)

Card in may be simulated by closing the contacts between 3 & 4 on CN10
D17 lights on CN10

System is waiting for contact with the mat

Step on the mat-D11 Exit mat lights up and motor starts to run

If door is stopped or contact is made with the safety nosing between the + and X position the door will go into the idle mode with the brake off, and may be pushed back or forward to the + position

Contact is cleared

Door makes contact with pedestrian

Contact is cleared

Exit the door

IDLE TEST (mode 2)

(If MCP does not read mode 2 ready... see SEC.21)


Card in may be simulated by closing the contacts between 3 & 4 on CN10

Mat is activated
Contact with safety nosing

Then...

Abandon

After a 5 sec. delay
The door will rotate through the X then the + position.




THIS CONCLUDES MODE 2 TESTING
GO TO NEXT PAGE FOR MODE 11 TESTING

14.2. BASIC SETUP (testing)

The following tests are designed to check all inputs and outputs. The tests are conducted in mode 2 (card/card +) and mode 11 (motec/motec). If motecs are used, plug in CN1 (motor and brake) and turn the breaker on.

MOTION DETECTOR ACTIVATION (mode 11)

(If MCP does not read mode 11 ready... see SEC.21)



Move into the detection zone - the door will start to rotate

The light on the reader bracket will be green

This cycle will continue as long as the motec zone is activated.

After activation, the will door rotate for 5 sec. (default) see parameter 23

After the zones are clear the unit returns to inactive status

15. DIAGNOSTICS CHART 1

SEE SECTION 5 FOR INTRODUCTION TO CONTROL SETUP

Accessing the diagnostics from the infrared control.

- The door must be inactive (in standby condition)
- Point the IR remote at the LCP and press unlock
- The red LED on the LCP display will flash - indicating the signal is being received.
- If the control was previously locked with a password, the LCP will show "P. I" to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.
- If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as P. I

•Press "SU" diagnostics will appear

The order in which the diagnostics are arranged

- 1 PSY
- 2 SPD
- 3 dr-U
- 4 br-1
- 5 br-2
- 6 EnC
- 7 InP
- 8 ua-1
- 9 CalJ
- 10 r-10
- 14 r-14
- 15 5SL
- 16 5EE

CHECK POWER SUPPLY

- After a few seconds diagnostic 1 will display or...
- Press 1 or "+" up "-" down
- Press "2"
- Displays DC voltage output of the power supply to operate the motor and the core brake. Voltage will fluctuate with changes in the incoming voltage. A typical value is 111 to 114 VDC

CHECK DOOR SPEED

- Press 2 or "+" up "-" down
- Press "2"
- Ramps the motor up to normal speed and displays it in RPM.
- Using the + and - keys on the IR remote the motor voltage may be changed in small steps (temporarily) to determine the motor voltage required for a desired speed. The actual voltage is change in parameters 1 and 2.

To choose this speed for Normal -- Press 1
Reduced - Press 2
Reverse - Press 3

Accessing the diagnostics from the control itself.


- The door must be inactive (in standby condition)
- Press and hold the DOWN button while briefly pressing RESET.

•The version number will display


•If the control is locked with a password it must be unlocked with the IR remote.

•Diagnostics/Setup will display

•Release the DOWN button



To return to the main diagnostics menu, press the "SU" button on the remote. Press the LOCK button, on the remote, or hold the DOWN button and briefly push the RESET on the control to exit all diagnostics and restore normal door operation.



If the door speed is changed re-do diagnostic 15 (Reset safety sensitivity levels)

16. DIAGNOSTICS CHART 2

H915.22

Accessing the diagnostics from the infrared control.

Accessing the diagnostics from the infrared control.

CHECK MOTOR VOLTAGE AND CURRENT

- Press 3 or "+" up "-" down
- Press "2"
- Displays motor amperage
- Useful for hunting mechanical binds
- Checking overall performance of the doors mechanics.



*Diagnostics/Setup
Check motor(LCP=I)?

- Press UP till 3 is reached
- Press SET
- Displays motor voltage and amperage

Motor = 61.1VDC
Motor = .54A

CHECK BRAKE VOLTAGE AND CURRENT

(LCP displays voltage)

- Press 4 or "+" up "-" down
- Press "7"
- Engages the core brake and displays the voltage.
- Voltage will fluctuate with line voltage changes.
- A value of 90 to 105VDC is typical.
- Verify that the brake engages mechanically and properly locks the door.
- Checks the brake control subsections of the control.



*Diagnostics/Setup
Check brake(LCP=V)?

- Press UP till 4 is reached
- Press SET
- Displays brake voltage and amperage

Brake = 97.0 VDC
Brake = 192 mA

CHECK BRAKE VOLTAGE AND CURRENT

(LCP displays current)

- Press 5 or "+" up "-" down
- Press "7"
- Brake current is displayed.
- Current is typically in the 200ma range



*Diagnostics/Setup
Check brake(LCP=I)?

- Press UP till 5 is reached
- Press SET
- Brake current and voltage are displayed

Brake = 97.0 VDC
Brake = 192 mA

Accessing the diagnostics from the infrared control.

ENCODER TEST

- Press 6 or "+" up "-" down
Press "2"

Encoder count is displayed up to 999. If the count exceeds 999 the LCP displays ---. The encoder count should increase smoothly as the door is pushed.

MANUAL ENCODER TEST

- Negative readings will not display - Both displays will be frozen at zero if the door is closed.
- To manually test the reverse operation of the encoder, push the door forward and then pull it back. The encoder will reverse the door forward and then reverse operation of the encoder.

POWER ENCODER TEST

- The encoder may also be checked by pressing the 1 key on the IR remote. The door will run forward at a slow speed - the speed may be changed up or down by using the + and - buttons on the IR remote. Pressing the 2 button will run the door in reverse. Press zero on the IR remote to return to manual encoder testing.

- Press 7 or "t" up e^n down

- Press "2"
- All the codes of all active inputs are displayed as they are polled.
- The input codes presented are as follows:

LCP	LCD
I.1	Reference switch
I.2	Trailing safety nosings
I.3	Leading safety nosings
I.4	Exit card reader
I.5	Entrance card reader
I.6	Exit handicap (slow) switch
I.7	Entrance handicap (slow) switch
I.8	Exit motion detector
I.9	Entrance motion detector
I.10	LCP key switch, SET (right) position
I.11	LCP key switch, SELECT (left) position
I.12	Reserve input
I.13	AUX B switch
I.14	AUX A switch
I.15	Fire alarm contact
I.16	Emergency stop switch
I.17	Reserve input
I.18	Reserve input
I.19	Reserve input
I.20	Reserve input


LCP	LCD	NC	an	sy	mt
21	Reserve input				
22	Up button on control				
23	Down button on control				
24	Set button on control				
25	AUX 4 input on E6010 mat interface card				
26	AUX 3 input on E6010 mat interface card				
27	AUX 2 input on E6010 mat interface card				
28	AUX 1 input on E6010 mat interface card				
29	Exit mat, trailing				
30	Exit mat, leading				
31	Entrance mat, trailing				
32	Entrance mat, leading				
33	Input 8 on E6008 aux.				DC input card
34	Input 7 on E6008 aux.				DC input card
35	Input 6 on E6008 aux.				DC input card
36	Input 5 on E6008 aux.				DC input card
37	Input 4 on E6008 aux.				DC input card
38	Input 3 on E6008 aux.				DC input card
39	Input 2 on E6008 aux.				DC input card
40	Input 1 on E6008 aux.				DC input card

NOTE: codes 33 thru 40 may appear if an E6004 card is NOT installed in the system. In this case the codes are meaningless.

18. DIAGNOSTICS CHART 4

Accessing the diagnostics from the infrared control.

- Press 8 or "+" up "-" down
- Press "?"
- Displays V.1, V.2, V.3 & V.4
- Use the "4" and "-" keys to select any of the voices stored in the control's speech memory.
- Use the "?" key to play the selection.
- Voices may be played from the IR control but not recorded
- To record a new message:
- Select the message to be replaced
 - Hold the SET button until REC appears. Hold it directly into the microphone. The total length of the message may not exceed 5 seconds.
- CAUTION:** Pressing the REC button will compress the message.
- The REC button is disabled at all times except when recording.
 - The factory default messages are:
 - Voice 1 "Security violation"
 - Voice 2 "Door will reverse"
 - Voice 3 "Please"
 - Voice 4 "Not recorded"



- Accessing the diagnostics from the control itself.**

- Press UP till 6 is reached
- Press SET
- UP DOWN
- RESET
- DOWN RESET
- UP DOWN
- SET
- The voice message will be displayed in text form. Use the UP and DOWN keys to select a voice message.
- Use the SET key to play that message.



- Press and hold the REC key
- Speak directly into the microphone

- ## CHECK STATISTICS

- Press 9 or "*" up "*" down
- Press "2"
- The code for the first statistic is displayed.



- Press UP  SET
9 is reached
- DOWN  RESET
- Press SET  DOWN  RESET
- Each statistic is displayed along with its corresponding value.

During normal operation a number of significant statistics are stored in the counter's internal memory. These counters hold the following information:

LCP	LCD
C.0	Entrance - number of cards accepted
C.1	Entrance - number of successful entrances
C.2	Entrance - number of attempted violations
C.3	Entrance - number of cancellations
C.4	Entrance - reserved counter
C.5	Entrance - reserved counter
C.6	Entrance - reserved counter
C.7	Entrance - reserved counter
C.8	Entrance - reserved counter
C.9	Exit - number of cards accepted
C.10	Exit - number of successful exits
C.11	Exit - number of attempted violations
C.12	Exit - number of cancellations
C.13	Exit - reserve counter
C.14	Exit - reserve counter
C.15	Exit - reserve counter

- To view a statistic:
Use the "4" and "-" buttons on the remote.
The Up and DOWN buttons on the control itself.
The number keys 0 thru 9 on the IR remote.
When the desired statistic is found, press the "+" on the remote or the SET button on the control to view the count on the LCP. (The LCD will already be showing the name and its count)
If the count is above 999 the LCP will display ---.
To clear a particular displayed count, press The F1 key on the IR remote. The control will ask for confirmation (LcF will display for ConfFirm).
To clear all counters press the "+" key on the IR remote or the UP button on the control.
To not clear all counters press the "-" key on the IR remote or the DOWN button on the control.
All counters will be retained, even with the power off.

19. DIAGNOSTICS CHART 5

Accessing the diagnostics from the infrared control.

RESERVED

- 10 •10 thru 14 are reserved diagnostics
- 11
- 12 •Press 10 thru 14 or "+" up "-" down
- 13 The number of each will display on the LCP
- 14

0 r 10

*Diagnostics/Setup
Resume diagnostic 10

•Press UP till
10 is reached

Accessing the diagnostics from the control itself.

LEARN SAFETY LIMITS

CAUTION: The door will move on its own when these routines (diagnostic 15 & 16) is initiated! Use extreme caution to avoid entrapment.

The C9150 control can measure the current draw of the door's motor and automatically set the "safety sensitivity" settings to the suggested values for the installation. These parameters are automatically set when a complete control setup is performed. A large adjustment in motor speed may require changing these settings. Instead of hand adjusting them, this routine will force the control to update the settings. Adjust the safety limits to individual requirements.

•Press 15 or "+" up "-" down

0 15

*Diagnostics/Setup
Learn Safety Limits?

•Press UP till
15 is reached

•Press "+"

0 55L

•This diagnostic will run 4 routines and store the highest current draw of each one.

•The highest current value for each routine is displayed on the LCP

0 0.56

Seeking + ref = 4

•The name of the routine and the highest current draw will be displayed on the LCD

•The door will proceed through 4 quarterpoints at:

Normal speed forward
then
Reduced speed forward

Parameter 6 Safety Sens - Fwd

Parameter 7, Safety Sens - Reduced
The highest running current will be stored and display and the parameter set at 200% of this value.



Forward at normal speed
then reduced speed

•The door will back up through 4 quarterpoints at:

Reverse speed

Parameter 8 Safety Sens - Reverse
The highest running current will be stored and display and the parameter set at 200% of this value.



Reverse speed

•The door will proceed forward to the:

Next quarterpoint

Parameter 10 Safety Sens - Startup
The highest startup current will be stored and displayed and the parameter set at 200% of this value.

•The display will return to the main diagnostic menu.

If the door speed is changed re-do diagnostic 15 (reset safety sensitivity levels)

NOTE:

Factory defaults are set for testing and may not be suitable for individual conditions. See parameters 6 thru 10 for manual setup of safety sensitivity

20. DIAGNOSTICS CHART 6

Accessing the diagnostics from the infrared control.


Accessing the diagnostics from the main control panel.

COMPLETE SETUP

COMPLETE SETUP
The door will move on its own when this routine is initiated! Use extreme caution to avoid entrapment.

CAUTION: The door will move on its own when this routine is initiated. Use extreme caution. This diagnostic can be the most **DESTRUCTIVE** if it is performed accidentally. This diagnostics allows a complete control setup to be performed. The diagnostic is performed by setting the door to factory default and all counters are set to zero.

All parameters will be set to factory default and all counters are set to zero. This diagnostic should always be performed when initially installing a door and never be performed without good reason otherwise.



It rotates the door through four quarterpoints and counts the total encoder pulses to determine how many pulses are present in each door quadrant.

- Finally, the door is rotated through additional quadrants to automatically set safety limits (see diagnostic 15).

Once all the above is complete, the display is returned to the main diagnostic menu.

- Press the lock key

• Press the **RESET** button.

***Diagnostics/Setup**

五品


T button
 LEFT
 UP DOWN
 RESET

NOTE: Factory defaults are set for testing and may not be suitable for individual conditions. Some parameters may require manual adjustment.

21. DOOR OPERATING MODES

The door must be inactive (standby condition) to change the mode.

KEY SWITCH MODE SELECTION



The key switch is used to select and change the mode.

The LCP and the remote control are used to select parameters, modes or run diagnostics.


SELECTING A MODE

Switch position



Move the keyswitch to the **SELECT** position.
When **595** appears on the LCP move the keyswitch to the **SET** position.

LCP display



Select door mode



With the keyswitch in the **SET** position the number of the current operating mode will appear on the **LCP**



Each time the keyswitch is moved back and forth from neutral to set the number changes on the LCP display (see the mode chart).



Release the key switch in the neutral position when the number of the desired mode appears on the LCP.
After a few seconds the door will resume operation in the chosen mode. Door will move after mode change.

NOTE

The number of available codes can be restricted to those required by the building management.
Using parameters 44-59, certain modes can be restricted so they can not be accessed by the keyswitch.

HARD WIRED MODE SELECTION

When parameter 60, remote mode select, is turned on, mode selection can NOT be made with the key switch or remote.
When remote select is in use, remote mode A selects the door mode to use when terminals 3 and 4 of CN5 are open. Hard wired remote mode B selects the mode to be used when terminals 3 and 4 are closed.
See parameter 60, 42 & 43.

MODE CHART

The following chart shows the 12 modes that are always available regardless of the software version available.

MODE	STANDBY POSITION	ENTRANCE	EXIT
0	+	No entrance	No exit
1	+	Motec arms mat	Motec arms mat
2	+	Card	Card
3	+	Card	Motec arms mat
4	+	No entrance	Card
5	+	No entrance	Motec arms mat
6	+	No entrance	Mat actuates
7	+	Card	Mat actuates
8	+	Mat actuates	Mat actuates
9	n/a	Freewheels	Freewheels
10	X	No entrance	No exit
11	X	Motec	Motec

Standard operating software for the C9150 control does NOT allow "X" operation, except for a totally secure or free access door. All of these software versions end in even numbers (4.00, 4.02...)


Software to permit "X" position operation is available for an additional charge due to a licensing agreement. These software versions end in odd numbers (4.01, 4.03...)

These versions add 4 unique "X" position modes as shown below, for a total of 16.

MODE	STANDBY POSITION	ENTRANCE	EXIT
12	X	Card	Card
13	X	Card	Motec
14	X	No entrance	Card
15	X	No entrance	Motec

21.1. DOOR OPERATING MODES (using the ir remote)

The door must be inactive (standby condition) to change the mode.



Accessing the modes from the infrared control.

To change the mode setting:

- Point the IR remote at the LCP and press "SU"
- System "SYS" will display
- While on SYS push "?" current mode will display
- Press + or - to change the current setting

To control the lights:

- Point the IR remote at the LCP and press "SU"
- System "SYS" will display
- Press + or - to toggle to the lights

22. PARAMETER CHART 1

- The door must be inactive (in standby condition)

Accessing the parameters from the infrared control.

- Point the IR remote at the LCP and press unlock 
- The red LED on the LCP display will flash - indicating the signal is being received.
- If the control was previously locked with a password, the LCP will show **UnL** to indicate that it is waiting for the unlock code. Enter the correct password within 5 seconds.
- If the correct password was entered or none was required, the parameter menu will be displayed. The display will be some parameter number such as **P.1**
 - Parameter will appear
 - Parameter value will appear
- To view or adjust the setting of a parameter, briefly press the "7"
 - Parameter value will appear
- Press the "+" or "-" key to change a yes or no or numeric parameter. Numeric values may be set with the number keys 0...9.
- Press the lock key to return to normal operation

The values shown for parameters in the following charts are default values that are set when the complete control setup is performed. In most cases these values will be acceptable for ideal door performance. Do not adjust control parameters without having a desired goal in mind.

Speed - (1)normal / (2)reduced / (3)reverse / (4&5) reserved

Parameters 1 thru 3 set the operating speed of the door during normal, reduced, and reverse run conditions (4 & 5 are reserved). The selected value directly equals the motor voltage. Acceptable values are 25 and up - the door will not turn below 25 volts. Horton suggest a run speed of 4 RPM.

CAUTION: Higher settings increase the possibility of serious injury to pedestrians. These parameters should be set at the lowest acceptable speed.

Accessing parameters from the infrared control.


- Press "+" up or "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up or "-" down or the number keys to change the value

1
2
3
4
5

Reserved parameters


Accessing the parameters from the control itself.

- Press and hold the **SET** button while briefly pressing **UP**.
 - Unlock will display
 - Release the set button
- The parameter name, number and current setting will appear.
- The parameter value is changed with the **UP** and **DOWN** buttons.
- Press reset to return to normal operation



NOTE:
After a few seconds with no entrys the display will switch back to the parameter number. The new value will be stored in memory

Accessing parameters from the main control panel.



23. PARAMETER CHART 2

Safety sens - forward / reduced / reverse / startup

Parameters 6 thru 10 (parameter 9 is reserved) set the sensitivity to increased motor current caused by obstructions to the doors. The default values are set at 15 - this means that a safety stop will occur if the motor current exceeds 1.5amps. During the control setup routine these values will be "tweaked" to 200% of the highest current found. For example: if during the forward run the maximum motor current detected was 1.2 amps, parameter 6 will be set at a value of 24 (2.4 amps).

Decreasing these values will provide greater safety and additional nuisance stops.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.

6	Press "+" up or the number keys to locate the desired parameter	P.6	Parameter 6	Press UP or DOWN to scroll	SET UP DOWN RESET
7	Press "7" to view the parameter	P.7	Safety Sens - forward Parameter 6: 15	Press SET to view the parameter.	SET UP DOWN RESET
8	Press "+" up or the number keys to change the value	P.7	Safety Sens - reduced Parameter 7: 15	Press UP or DOWN to change the setting	SET UP DOWN RESET
9		P.8	Safety Sens - reverse Parameter 8: 15		
10	Reserved parameter	P.9	Safety Sens - reserved Parameter 9: 15		
		P.10	Safety Sens - startup Parameter 10: 0		

NOTE: If parameter 6, 7 or 8 is automatically set to 20 or more by the setup routine, or parameter 10 was set at 45 or more, excessive motor current is being drawn which may indicate a mechanical problem or a bind in the door.

All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0seconds. A setting of 20 = 2.0 seconds.

Safety stop time fwd / rev

Parameters 11 & 12 determine how long the door will remain locked after a safety stop before it continues. Values below 20 (2.0 seconds) are NOT recommended.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.

11	Press "+" up or the number keys to locate the desired parameter	P.11	Parameter 11	Press UP or DOWN to scroll	SET UP DOWN RESET
12	Press "7" to view the parameter	P.11	Safety stop time-fwd Parameter 11: 35	Press SET to view the parameter.	SET UP DOWN RESET
	Press "+" up or the number keys to change the value	P.12	Safety stop time-rev Parameter 12: 35	Press UP or DOWN to change the setting	SET UP DOWN RESET

24. PARAMETER CHART 3

Inactive timeout

Parameter 13 sets the time the door will wait for mat activity before it "times out" following a valid card or motion detector presentation. When the door times out, it returns to the standby condition as follows:

- All card requests are cancelled, if any were active.
- All motion timers are reset to zero.
- Parameter 13 is meaningless during "X" quarterpoint operation.

Accessing parameters from the infrared control.

- Press "+" up or "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up or "-" down or the number keys to change the value

P. 13

50

Accessing parameters from the main control panel.

- Press UP or DOWN to scroll to locate the desired parameter.
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

All time delay parameters are measured in 1/10 second intervals. Example: a parameter setting of 100 = 10.0seconds. A setting of 20 = 2.0 seconds.

Security pass timeout

Parameter 14 sets the time the door will wait before it "times out" following a security pass request.

- When the door times out, it returns to standby condition.
- Parameter is meaningless during "X" quarterpoint operation.

Accessing parameters from the infrared control.

- Press "+" up or "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up or "-" down or the number keys to change the value

P. 14

100

Accessing parameters from the main control panel.


- Press UP or DOWN to scroll to locate the desired parameter.
- Press SET to view the parameter.
- Press UP or DOWN to change the setting

25. PARAMETER CHART 4

Idle mode timeout

Parameter 14 sets the time the door will wait for mat activity before it "times out" and proceeds to the next quarterpoint after it has been forced into the idle mode by a safety stop. The door must be totally idle before this timer begins running. Any activity whatsoever resets this delay. If parameter 15 is set to 100 and no cards, mats or motion detectors are encountered for 10 seconds following a safety stop to idle, the door resets itself by proceeding forward at reduced speed to the next quarterpoint position (either "+" or "X").

Accessing parameters from the infrared control.



Entry / exit alert time

Parameter 16 & 17 set the amount of time the entry and exit alert devices sound when a valid card is presented.

- Longer times may result in each user not receiving a separate alert.
- Example: if these parameters are set for a 5 second alert and 2 cards are presented within 3 seconds.
- Very short times are not recommended, since the user will have difficulty hearing the alert.


Accessing parameters from the infrared control.



Verify contact time

Parameter 18 sets the length of time that the "entry / exit" verification relay contacts are active following a validated entry or exit.

Accessing parameters from the infrared control.



26. PARAMETER CHART 5

Reserved time

Parameter 19 thru 22 are reserved time delays for future use. There values are currently ignored by the software.

Accessing parameters from the infrared control.



Motec delay time (X)

Sets the length of time that the door runs when an active motion detector is triggered in any "X" mode of operation. This parameter allows adjustment of the total time that the door remains active without having to set the delay in the motion detectors themselves.

Accessing parameters from the infrared control.




Safety stops to Idle

Parameter 24 sets the number of safety stops that must be encountered before the door switches to "Idle" mode.

- With the default value of 1 in use, the first motor overcurrent or nosing encountered places the door in the idle mode.
- If a value of 2 is used, the first safety stop will stop the door and lock the brake for the duration of the time set in parameter 11. After this timer expires, the door will attempt to move forward again. A second motor overcurrent or nosing will place door in idle mode.
- Values higher than 2 will result in additional "lock the brake" sequences before an idle is permitted.
- If idle operation is never desired, parameter 24 may be set to every high value such as a 100.
- The safety stop counter is reset at every "+" quarterpoint. "Idle" operation is not permitted during the 45° of door revolution for each "X" position to the following "+" position. If motor overcurrent or a safety nosing is encountered in this door quadrant, the door always locks the brake (if required) and times the safety stop.

Accessing parameters from the infrared control.



27. PARAMETER CHART 6

(25) Max entry / (26) exit cards

Parameters 25 and 26 set the maximum number of entry and exit cards that are permitted in the card stacks at any time. Additional card requests are ignored.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.




Backup warnings

Parameter 27 sets the number of complete voice annunciations that will be performed following an attempted security breach before the door backs up.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.




Network address

Parameter 28 sets the "address" of this particular door control. This parameter is used only when the door is part of a network of interconnected doors for building management, central control, etc. Setting the address to 0 disables all networked operations.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.




Reserved

Parameters 29 through 37 are reserved for use in future software

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.



28. PARAMETER CHART 7

Relay (38)K2, (39)K3 & (40) K4 mapping

Parameters 38, 39 and 40 set the function of relays K2, K3 and K4 on the motherboard.

Accessing parameters from the infrared control.



When set to the following values, each relay may be used to perform any of the following functions.

- | | |
|--|--|
| 0 Relay disabled - no function | 6 Entrance is permitted ("green light") |
| 1 Door in idle mode | 7 Exit violation attempt in progress |
| 2 Door is busy | 8 Exit verification (parameter 18 sets duration) |
| 3 Entrance violation attempt in progress | 9 Exit alert (parameter 17 sets duration) |
| 4 Entrance verification (parameter 18 sets duration) | 10 Exit is permitted ("green light") |
| 5 Entrance alert (parameter 16 sets duration) | 11 Door is secured |
| | 12 Violation lockdown signal |

More than one relay may be used for the same function, if additional contacts are needed.


When mapped to function 11, the relay doubles as a power failure detection contact, since the relay will be held on whenever the door is secured.

- 13 Leading nosing shorted after (X) position.
- 14 Door jams without tripping safety nosing (torque stop).
- 15 Combination of functions 12, 13 & 14.

Default door mode

- Parameters 41 works in conjunction with parameter 63, fixed power-up mode, to determine how the door operates when power returns after a power failure.
- If parameter 63 is turned on, parameter 41 determines what mode the door uses after power returns.
 - The default is mode 2 ("+" operation, card in / card out.)
 - If parameter 63 is turned off, the door always returns to whatever mode was in use prior to the power failure.

Accessing parameters from the infrared control.



29. PARAMETER CHART 8

Hardwired (42) mode A / (43) mode B


Parameters 42 and 43 are only active if parameter 60, hard wired mode select, is turned on.

When remote mode select is in use:

- Remote mode A selects the door mode to use when Aux A input is not active (terminals 3 & 4 of CN 5 are open).
- Remote mode B selects the door mode to use when Aux A input is active (terminals 3 & 4 of connector CN5 are shorted together)
- Parameters 42 and 43 are use when the door mode is remotely controlled by a building management system.
- If Parameter 60, remote mode select, is not in use the door mode is set with the LCP and parameters 42 and 43 are meaningless.

42
43

Accessing parameters from the infrared control.



Accessing parameters from the main control panel.



Mode 0 thru 15 permitted


Parameters 44 through 59 determine which modes are available at the keyswitch (LCP). Any mode that is set to NO will be skipped when the keyswitch is used to select a new door mode.

EXAMPLE: Setting parameter 53, mode 9 permitted, to "no" (door freewheel) mode cannot be selected by the keyswitch.

If the software does not enable the "x" operation, the default setting for mode 12 permitted thru mode 15 permitted is "no". In these restricted versions, these parameters can be changed to "yes" by the technician, but the keyswitch will continue to skip over the unpermitted modes.

If an attempt is made to use the restricted modes by enabling parameter 60, remote mode select, and setting either parameter 42, remote mode A, or parameter 42, remote mode B, to a restricted mode, the door will default to mode 2, "x" operation card in / card out instead "X" operation requires an upgrade in software.

Accessing parameters from the infrared control.



Accessing parameters from the main control panel.



- 44 = 0
- 45 = 1
- 46 = 2
- 47 = 3
- 48 = 4
- 49 = 5
- 50 = 6
- 51 = 7
- 52 = 8
- 53 = 9
- 54 = 10
- 55 = 11
- 56 = 12
- 57 = 13
- 58 = 14
- 59 = 15


30. PARAMETER CHART 9

Remote mode select

Parameters 60 determines whether the door's operating mode is set locally by the keyswitch (LCP) or remotely by a building management system. (See remote mode A, parameter 42, for additional information).

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.




Slows to qpt x modes

When parameter 61 is turned on, the door will slow from normal speed to reduced speed at the final "+" position just prior to quarterpointing in any "x" mode of operation.

Parameter 61 is only used in conjunction with "X" operation.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.




Clears mats every cycle

When parameter 62 is turned on, the door will stop at every "+" position regardless of whether another entrance or exit is permitted or not, and will insist that all mats be cleared after each cycle before the next cycle is permitted.

Parameter 62 is only used in connection with "+" operation.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.



31. PARAMETER CHART 10


Fixed power-up mode

If parameters 63 is off, after a power failure or other system reset the door will always return to the mode of operation last in use.
If parameter 63 is on, the door will use the mode selected in parameter 41 - default door mode.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up "-" down or the number keys to change the value



Locked in auto mode


Parameter 64 chooses whether the brake will be locked in modes that do not require it.

- Mode 8 (mat in/out), mode 9 (freewheel), mode 10 (motec in/out) do not require the core brake. All other modes are completely or partially secured, and the brake will always be used.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up "-" down or the number keys to change the value




MAT ACTIVATION / CARD ACCESS

If this parameter is turned off, card access is allowed whether mat is activated or not. If parameter is turned on and mat is activated card access is denied.

Accessing parameters from the infrared control.

Accessing parameters from the main control panel.

- Press "+" up "-" down or the number keys to locate the desired parameter
- Press "7" to view the parameter
- Press "+" up "-" down or the number keys to change the value



Reserved

Parameters 66 through 99 are reserved on/off. They are not used by the current software.

Violation lockdown

If parameters 99 is off, (DEFAULT) the door will lockdown if a forced entry is attempted and the door is pushed approx. 4" opposite its direction of rotation. A signal will be sent to the security system if available. (K2, K3 or K4 must be mapped to value 12)

If parameter 99 is on, the door will not lockdown, but a signal will be sent to the security system if available. (K2, K3 or K4 must be mapped to value 12)

Access and set the parameter as described above

32. PARAMETER QUICK REFERENCE CHART

PARAMETER	FUNCTION	DEFAULT	Comments	SECTION
1	Speed - Normal	60	The selected value = the motor voltage (see diagnostics 2 for run speed)	22
2	Speed - Reduced	45		
3	Speed - Reverse	45		
4	Reserved	0	Sensitivity of the door's safety circuit to obstructions	22
5	Reserved	0		23
6	Safety sens - Forward	15		
7	Safety sens - Reduced	15	Time delays are measured in 1/10 sec (35 = 3.5 sec)	23
8	Safety sens - Reverse	15		24
9	Safety sens - Reserved	15		24
10	Safety sens - Startup	0	Not used in "X" quarterpoint operation Not used in "X" quarterpoint operation	25
11	Safety stop time fwd	35		
12	Safety stop time rev	35		
13	Inactive time out	50	Time duration is set with parameter 11	25
14	Security pass time out	100		26
15	Idle mode time out	100		
16	Entry alert time	15	Only used when the door is part of a network	27
17	Exit alert time	15		28
18	Verify contact time	10		
19	Reserved time delay	10	Used in conjunction with parameter 63 Parameter 60 must be turned on Parameter 60 must be turned on Mode that is turned off is skipped by the keyswitch (See modes chart)	29
Thru				29
22	Reserved time delay	10		30
23	Molec delay time (X)	50	Mode that is turned off is skipped by the keyswitch (See modes chart) When this parameter is turned on, the door mode is controlled remotely by hard wired device Only used with "X" quarterpoint operation Only used with "X" quarterpoint operation If this parameter is on, the door will use the mode selected in parameter 41	30
24	Safety stops to idle	1		30
25	Max entry cards	25		31
26	Max exit cards	25	Eliminates the use of the brake in modes 8,9 and 10 Off card access allowed any time - On while mat sensor is active card access is denied	
27	Backup warnings	1		
28	Network address	0		
29	Reserved	0	Locks the door if it is forced in the direction opposite to its rotation. Entrapment can occur	31
Thru				
37	Reserved	1		
38	Relay K2 mapping	0	Mode 15 permitted Hard wired mode select Slows to opt x modes Cir mats every cycle Fixed power-up mode Locked in auto modes Mat actv / card access Reserved	
39	Relay K3 mapping	0		
40	Relay K4 mapping	0		
41	Default door mode	11	Reserved	
42	Remote mode A	2		
43	Remote mode B	2		
44	Mode 0 permitted	3	Reserved	
Thru				
59	Mode 15 permitted	Yes		
60	Hard wired mode select	Yes	Reserved	
61	Slows to opt x modes	Off		
62	Cir mats every cycle	Off		
63	Fixed power-up mode	Off	Reserved	
64	Locked in auto modes	Off		
65	Mat actv / card access	Off		
66	Reserved	Off	Reserved	
Thru				
98	Reserved	Off		
99	Violation lockdown	On		

33. DIAGNOSTICS QUICK REFERENCE CHART

DIAG	FUNCTION	Comments	SECTION
1	Check power supply	Displays DCV output of the power supply to operate the motor & brake	15
2	Check door speed	LCP displays door revolutions MCP displays motor voltage & RPM	15
3	Check motor voltage & current	LCP displays motor current, MCP displays motor current & voltage	16
4	Check brake voltage & current	LCP displays brake voltage, MCP displays brake current & voltage	16
5	Check brake voltage & current	LCP displays brake current, MCP displays brake current & voltage	16
6	Encoder test	LCP and MCP display encoder count in each quadrant	17
7	Testing inputs	LCP displays codes of active inputs, MCP displays text of active inputs	17
8	Voice	Play back or record a message	18
9	Check statistics	LCP displays code, MCP displays statistic and its value	18
10	Reserved	Reserved for future use	19
11			19
12			19
13			19
14	Reserved	Reserved for future use	19
15	Learn safety limits	Sets the safety limits by current sensing	19
16	Complete setup	Restores factory default settings to all parameters, and zeros all counters	20

34. ERROR CODES

All errors except 7 are considered major and require a keyswitch reset to clear them and restart the door.

LCP
display

- Er 1** Direction error (the door was pushed in the wrong direction when not in idle).
If the door is properly set up this run time error will never be seen because the safety stop will kick in before the door can be stopped manually and pushed in the wrong direction.
- Er 2** Drive system failure - This is either a run time or setup error and indicates that the motor could not be ramped to the proper voltage.
- Er 3** Motor current excessive - only occurs during setup phase
- Er 4** No reference switch - only occurs during setup phase
- Er 5** Encoder phasing incorrect - only occurs during setup phase
- Er 6** No encoder pulses received - only occurs during setup phase
- Er 7** Brake failure - A run time error that is displayed if insufficient brake voltage and / or current are detected when the door is supposed to be secure. It is self-clearing when proper voltage is restored.
- Er 8** High voltage DC failure
- Er 9** System failure

