



5100 Series Sliding Door Installation Instructions



SERIES 5200 ALL-GLASS "SX" BREAKOUT ADJUSTMENT

OCT'06





SX BREAKOUT ADJUSTMENT & TROUBLESHOOTING

May'07

To minimize the drop of a large sliding door when breaking it out, please follow the checklist below:

- 1. Verify the glass setting blocks in the SX panel are placed in the proper locations around the glass as per page 11 of the Series 5100 Installation Instructions.
- 2. Verify the top pivot / breakout mechanism is adjusted for maximum lift as described on page 11 of the Series 5100 Installation Instructions.
- 3. Verify a door wheel is installed in the bottom of the vertical lead stile of the door.
- 4. Lower the door as much as possible by adjusting the ¼-20 height adjustment screws on top of the door (see page 9 of the Installation Instructions). The door and door wheel should not be contacting the threshold/floor when the door is not broken out. A nominal clearance of 1/8" is desired.
- 5. With the door slightly broken out, inspect for any misalignment between the two fingers on the underside of the top carrier assembly and the mating stamping in the top of the vertical lead rail. If required, bend the outside end of the fingers downward slightly until the fingers properly align.

