


★★★★★
TORMAX[®]
AUTOMATIC



Installation and Service Manual
1102/ TTX Swing Door Operator
TORMAX 1201 Swing Door Operator

Warning - To reduce the risk of injury of persons - Use this operator only with swing doors.

TORMAX USA Inc.

12859 Wetmore Road
San Antonio, TX 78247
210-494-3551
210-494-5930 (FAX)
888-685-3707
www.tormaxusa.com
info@tormaxusa.com

Issue Date: 05/04/2018
P/N : US801918
Version: FW_3.11

TABLE OF CONTENTS

SECTION	PAGE
Table of Contents	2
Important Information	
Safety Warnings, Installation & Service, Glazing	3
Intended Installation Environment, Door Operation, ANSI/ BHMA	4
Operator Applications, Country Code, User mode with FCP	5
1. Modes of Door Operation	6
2. Components Overview	7
3. Applications	8
4. On-Board Programming Configuration Tool - Description	9
5. System Values for Application	10
Installation	
6. Applications:	
Outswing 8-10 lbs. Spring Force Installation/ Commissioning	11 - 12
Outswing 18-20 lbs. Spring Force Installation/ Commissioning	13 - 14
Inswing 0" Reveal Installation/ Commissioning	15 - 16
Inswing 0"-6" Reveal Installation/ Commissioning	17 - 18
Double Egress Application Installation	19
Pair/ Double Egress Application Wiring	20
Pair/ Double Egress Application Commissioning	21
7. Adjustments:	
1102/ 1201 Open Door Stop, 1201 Spring Tension	22
Frequently Used	23
8. Slim Line Header	
Header Preparation	24
Application Illustrations	25
9. Programming with the FCP - Overview, Example	26 - 28
10. Commissioning with FCP	
Commissioning, Adjustments	29 - 30
On-Board Codes 3, 6, 7 Descriptions/ BDM LED Display	31
11. Programming & Trouble Shooting Tables	32 - 36
12. Control Connection Diagram	37
13. Wiring Diagrams	
Single Applications	38 - 42
Pair / Double Egress Applications	43 - 47
14. Technical Specifications:	
Shaft Removal	48
T1253 Cable Plan	49
T1633 1201 Technical Information	50
T1634 1102 Technical Information	51
Electrical Requirements for Installation	52
T1753 Double Door Application	53 - 54
T1637 Basic Door Module (BDM) MCU42-BDM-A	55 - 56
T1638 Exterior Door Module (EDM) MCU42-EDM-A	57 - 58
T1640 Multi-Door Module (MDM) MCU42-MDM-A /B	59 - 60
T1639 Power Door Module (PDM) MCU42-PDM-A	61 - 62
T1691 Programming Interface Module (PIM) MCU42-PIM-A	63
T1757 Functional Control Panel (FCP) MCU32USIN-7-A	64 - 65

Important Information

SAFETY/ WARNINGS SYMBOLS



NOTE indicates important information specific to the process or steps being performed.



ELECTRICAL VOLTAGE indicates that electrical voltage is present and that caution should be taken to prevent injury or property damage.



CAUTION indicates failure to follow instructions may result in personal injury and/ or property damage.



OPTIONAL COMPONENTS indicates components that are not installed in all systems.



**WARNING - Failure to observe the information in this manual may result in personal injury or damage to equipment. To reduce the risk of injury of persons use this operator only with pedestrian swing doors.
Save these instructions for future reference.**

Installation and Service

Any and all TORMAX equipment must be installed, serviced and inspected by an AAADM Certified technician, to meet the current ANSI A156.10 and/ or ANSI A156.19 standard and any local or state building codes.

The person responsible for the daily operation and maintenance of the system is referred to as "End-User".



It is the technicians responsibility:

1. Review the functions of the equipment with the end-user. *Failure to do so, may lead to the improper use, could cause injury to persons and/ or damage to the equipment.*
2. Familiarize the end-user with the Daily Safety Check Decal and how to perform the walk test procedures.
3. Illustrate to the end-user how to place the door out of service (turn off power or place in P mode or OFF mode of operation), if the equipment does not perform as described in the Daily Safety Check Decal.
4. Recommend to the end-user to have their equipment inspected annually by an AAADM certified technician.

Glazing

The glazing material of all doors shall comply with the requirements of ANSI Z97.1, American National Standard Performance Specifications and Methods of Test for Safety Glazing Material Used in Buildings.

Important Information

Intended Installation Environment

The 1102/ TTX and the 1201 are non-handed swing door operators that can be used on interior or exterior doors.

The operator is mounted above the door on the inside of the building. Any other use, or any use exceeding this aim, is deemed as not used in accordance with its intended purpose.

The manufacturer will not be liable for damages resulting from such applications or warranty the product. Arbitrary changes to the system will exempt the manufacturer from any liability for damage resulting from this.

The 1102/ TTX is designed as a Low Energy operator to comply with ANSI A156.19 standard.

The 1201 can be utilized as a Low Energy operator and comply with ANSI A156.19 standard, or setup to operate as a Power Operated Pedestrian Door and comply with ANSI A156.10 standard.



Upon completion of the installation the technician should perform an AAADM inspection to ensure that the door complies to the appropriate standard ANSI a156.19 or ANSI A156.10 in which it is setup to operate within.

Door Operation

The 1102/ 1201 mode of operation is control by a 3-position switch (standard) or a (FCP) Functional Control Panel (optional). The primary mode of operations are:

Off - The door remains in the closed position with lock engaged, but can be opened by the Key Switch activating input.

Automatic - Two-way traffic, typical setting for normal operation. Allows the interior & exterior sensors, Key switch and safety devices (if applicable) to operate the door.

Hold Open - The door goes to the open position and remains there until the switch is taken out of this position.

Upon a power loss the operation of the 1102/ 1201 operating system will function according to specifications:

Immediate spring closing.

The operator functions as a manual door closure.

Lock function will operate to specification (fail secure/ fail safe).



Continued operation , if equipped with a battery backup.

ANSI/ BHMA A156.10, A156.19 standards - Knowing Act Switch

Doors activated by a manual switch must have the switch installed in a location from which the operation of the door can be observed by the person operating the switch. Refer to the latest revision of ANSI/ BHMA A156.10 or A156.19 for location of Knowing Act switch and time delays.

Important Information

Operator Applications

The 1102/ 1201 are Surface Applied (SA) operators and are power open and spring close. Basic configuration adjustments will be made with an on-board programming button.

The operator has 2 standard applications:

- Outswing - The operator pushes the door open.
- Inswing - The operator pulls the door open.

Within each standard application there are important points to know and consider during the installation process.

Outswing: 8-10 lbs. of manual opening force (Low Energy ANSI A156.19) or Knowing Act Door Activation (Power Operated Pedestrian Door ANSI A156.10)

18-20 lbs. of manual opening force (Power Operated Pedestrian Door ANSI A156.10)

- InSwing: 0" reveal, non-handed arm
- 0" - 6" reveal, handed arm

Country Code

The Country code is available in firmware V3.02 and above. The country code provides preset values to aid the technician in installing the door to comply with ANSI Standard A156.19. This does not eliminate the need for an AAADM inspection to be performed for compliance. Additional adjustments may need to be made upon inspection.

“U” User mode on FCP

The User mode has two options:

- UR - Ability to read specific programming parameters without changing the parameter.
- UP - Ability to change programming parameters within a limited range.

Refer to programming table for specifics.




Recommend using “P” programming mode to have full range of adjustments on all parameters.

Modes of Door Operation

Modes of operation can be selected with either the standard 3-position switch or the optional 6 position Functional Control Panel (FCP).

The technician will review the appropriate mode switch with the end-user.



- 1. OFF** - The interior and exterior activators are inhibited after the door reached the fully closed position, if an electric lock is present it will be activated. Door will cycle open, if a signal is sent to the key switch input.



- 2. AUTOMATIC** - Typical setting for normal 2-way traffic operation with interior and exterior activators, key switch input and safety devices operating the door.



- 3. REDUCED OPERATING** - Allows the door to open with a reduced opening width. Activators and safety devices operate the same as automatic mode.



- 4. EXIT** - (1-way traffic) Allows interior activator and key switch inputs to operate the door. The exterior activator input is inhibited from opening the door while the door is closed. When the door is opened/ closing the exterior activator becomes operational and will re-open a closing door.




- 5. HOLD OPEN** - Hold and maintains the door in the open position.




- 6. (P) MANUAL OPERATION** - Allows the door to be used manually without the use of sensors. Push and pull motion applied to the door to open and close the door.

Components Overview

Single Door




Double Door



- | | |
|--|---|
| 1 Primary drive TORMAX 1102/1201 | 11 Battery unit |
| 2 Secondary drive TORMAX 1102/1201 | 12 Header cover |
| 3 Adjustment of spring force TORMAX 1201 only | 13 Side plate |
| 4 Adjustment of internal open end stop | 14 Mounting profile |
| 5 Shaft 2.48 in. (63 mm) | 15 Upgrade modules MDM, PDM, EDM |
| 6 Shaft 3.22 in. (82 mm) | 16 Functional Control Panel (FCP) User interface (Option) |
| 7 Shaft 4.84 in. (123 mm) | 17 On/Off/Hold Open mode of operation switch (Standard) |
| 8 Out-Swing (Push) Arm 11.41/ 13.77 in. (290/350 mm) | 18 Sync Cable for pairs |
| 9 In-Swing (Sliding Pull) Arm 13.77/ 19.68 in. (350/500 mm) | 19 Shaft retaining bolt |
| 10 In-Swing (Slide/ Pull) Arm w/Panic 19.68 in. (350 mm)
(not available at this time) | |

APPLICATIONS




On-Board Programming Configuration Tool - Description

Overview

The On-board programming tool allows the installer to commission the operator without the use of the FCP. If additional changes are needed i.e. time delay, push-n-go the FCP will be required.

The on-board programming tool utilizes the programming button, green & yellow LEDs and an audible tone device to aid the installer during the commissioning process. During the commissioning process, the LED's flashing sequence and audible tone will continually repeat until a selection is made, then the audible tone and flashing sequence changes for the next parameter selection.

On-board Configuration Tool Familiarization



- 1 Base door module BDM
- 2 Programming Button
- 3 LED GREEN: status display (control system ready for operation) or configuration display.
- 4 LED YELLOW: error display or configuration display

Programming functions can be launched by means of the programming button.


The GREEN LED supports parameter selection → Release the button at the right point in time.

The YELLOW LED indicates the parameter by a series of flashes → Press the button at the right point in time.

Programming Procedure – General

- Keep the programming button depressed. The GREEN LED starts to *FLASH* at one second intervals for a short time. The number of flashes corresponds to the programming code as in the programming table.
- Release the programming button after the required number of *GREEN FLASHES*.

Example: Code 5 “Factory Reset” (see below for codes)



Programming Codes



In order to ensure the safety of the system, please follow the details of the programming steps in the following pages.

Code 1: Commissioning (enter system values, preloads, performs learn)

Code 2: (Consult factory)

Code 3: Detecting/mask out safety features

Code 4: Spring pre-tension parameter (only applicable for TORMAX 1201)

Code 5: Factory reset (Reset all values, excluding operator type)

Code 6: Repeat commissioning (without entering system values, door preloads, performs learn)

Code 7: Preset value 1 = Low Energy (preset values for multiple parameters)

System Values for the Application

System Values

After installing the operator determine the 3 system values. Measure the dimensions shown in the illustrations below, select each system value listed below the measurement. Write these numbers down as they are referenced during commissioning.

Audible Tone
 1

Door width

28"	32"	36"	40"	44"	48"	*52"	*56"	Door width
1	2	3	4	5	6	7	8	Value 1

1102 Yellow LED Green LED
1201 Yellow LED

System Values

Audible Tone
 2

Reveal

0 - 2"	2 - 4"	4 - 6"	6 - 8.5"	8.5 - 10.5"	10.5 - 12.5"	Distance A
1	2	3	4	5	6	Value 2

Yellow LED Green LED



Audible Tone
 3

Drive Arm


Outswing			Inswing			
11-3/8"	Custom	13-3/4"	A	Custom	B	Lever length C
1	2	3	4	5	6	Value 3

Yellow LED Green LED

Outswing - Low Energy 8 - 10 lbs Spring Holding Force





- 1) Determine the handing of the operator according to the door. Note that arrow on operator indicates opening direction of rotation.
- 2) Locate & mark output shaft location 12-3/16" from CL of hinge onto door frame
- 3) Align header at the bottom of the door frame as shown below.
- 4) Secure header to the wall with appropriate hardware.
- 5) For Stainless Steel Arm refer to illustration on page 13 for mounting dimensions.
- 6) Locate and mount door arm attachment bracket to the door at Y dimension for shaft used and 14-1/4" from CL of hinge as shown below.
- 7) Insert shaft/ drive arm (6) into the operator perpendicular to the door as shown below. **Tighten shaft bolt to 25 ft/ lbs.**
- 8) Manually rotate drive arm (8) as shown below 40°-45°, check connection point of the two arms to determine how much of the door portion arm (7) may need to be shortened and/ or cut off to connect the two arms.
- 9) Proceed to page 12 to perform commissioning.



X: Clearance required (distance bottom of header to top of arm)
 Y: Distance between bottom of header back plate and centerline of door mounting shoe

Part No.	Shaft Length	X	Y
141032 (STD)	3-7/32" (82mm)	1-1/16" (27mm)	1-7/16" (36mm)
141106 (D.E.)	3-15/16" (100mm)	1-25/32" (45mm)	2-5/32" (55mm)
141205	4-27/32" (123mm)	2-11/16" (68mm)	3-1/16" (78mm)

For extended reveals contact TORMAX



Outswing - Low Energy 8 - 10 lbs Commissioning



Requirements

1. Shaft should be secured into drive unit during mechanical installation.
2. Refer to page 22 to adjust open door stop.
3. Determine system values for your application based on the illustrations on page 10.

Commissioning



Commissioning Example: (3) = 36" door width, (1) = 0-2" reveal, (1) = Standard outswing Arm 11 3/8.



Press & Hold Programming Button, **Release** after **1 Green LED** Flash. The operator will make 1 beep and immediately begin to flash the **Yellow LED**.

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 1X, then after 3 yellow flashes, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 2X, then after 1 yellow flashes, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 3X, then after 1 yellow flashes, **Press & Release** Programming Button

MADE AN ERROR DON'T WORRY: To start over Disconnect Power for 10 seconds, Reconnect Power, then **Press & Hold** Programming Button and **Release** after **5 Green LED** Flashes.

The operator will open 20 degrees stop and beep 2x. **Press & Release** programming button. The operator will slowly close and beep 2x, next it will slowly fully open and beep 2x, then close (beep 1x) followed by 5 beeps, and will cycle fully open & close at normal speed.



Enter Country Code 7 1: (**Read Entire Step BEFORE attempting to enter Country Code**)

PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.

Press & Hold programming button, **Release** after **7 Green** flashes then immediately **Press & Release** programming button after **1 Yellow** flash.



Programming is complete - for further programming enhancements refer to page 23 or Programming Tables

Outswing Full Pedestrian 18 - 20 lbs Spring Holding Force



- 1) Determine the handing of the operator according to the door. Note that arrow on operator indicates opening direction of rotation.
- 2) Locate & mark output shaft location 12-3/16" from CL of hinge onto door frame
- 3) Align header at the bottom of the door frame and CL of the shaft location as shown below.
- 4) Secure header to the wall with appropriate hardware.

- 5) Locate and mount door arm attachment bracket to the door at Y dimension for shaft used and 16-1/8" from CL of hinge as shown below.
- 6) Insert shaft/ drive arm into the operator, **leave shaft bolt loose until appropriate step during commissioning procedure.**
- 7) Proceed to page 14 to perform commissioning.



X: Clearance required (distance bottom of header to top of arm)
 Y: Distance between bottom of header back plate and centerline of door mounting shoe

Part No.	Shaft Length	X	Y
141032 (STD)	3-7/32" (82mm)	1-1/16" (27mm)	1-7/16" (36mm)
141106 (D.E.)	3-15/16" (100mm)	1-25/32" (45mm)	2-5/32" (55mm)
141205	4-27/32" (123mm)	2-11/16" (68mm)	3-1/16" (78mm)

For extended reveals contact TORMAX

Outswing Full Pedestrian 18 - 20 lbs Commissioning



Requirements

1. **Shaft should be loose in the drive unit. Drive arm connected to door and shaft.**
2. Determine system values for your application based on the illustrations on page 10.

Commissioning



Commissioning Example: (3) = 36" door width, (1) = 0-2" reveal, (1) = Standard outswing Arm 11 3/8.



Press & Hold Programming Button, **Release** after **1 Green LED** Flash. The operator will make 1 beep and immediately begin to flash the **Yellow LED**.

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 1X, then after **3 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 2X, then after **1 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 3X, then after **1 yellow flashes**, **Press & Release** Programming Button

MADE AN ERROR DON'T WORRY: To start over Disconnect Power for 10 seconds, Reconnect Power, then **Press & Hold** Programming Button and **Release** after **5 Green LED** Flashes.

The operator will open 20 degrees stop and beep 2x. Attach Door Arm to Shaft and Door, place the Door in the Closed Position, and **NOW** Tighten the shaft to the operator at 25 ft-lbs. REMOVE POWER from Operator and adjust open door stop to desired position, refer to page 22 for adjusting internal Open Door Stop.

RECONNECT POWER (operator beeps 1x), then **Press & Hold** programming button & **Release** after **6 Green LED** Flashes. The operator will open 20 degrees stop and beep 2x. **Press & Release** programming button. Operator will slowly close and beep 2x, next slowly fully open & beep 2x, then close (beep 1x) followed by 5 beeps, and will cycle fully open & close at normal speed.


Commissioning is complete for High Energy Applications. For Low Energy application complete the last step below Program the country code into the controller. For additional programming refer to page 23 or Programming Tables.

Enter Country Code 7 1: (Read Entire Step BEFORE attempting to enter Country Code)

PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.


Press & Hold programming button, **Release** after **7 Green** flashes then immediately **Press & Release** programming button after **1 Yellow** flash.

Inswing (Pull) Arm 0" Reveal Installation



- 1) Determine the handing of the operator according to the door. Note that arrow on operator indicates opening direction of rotation.
- 2) Locate & mark output shaft location 12-3/16" from CL of hinge onto door frame as
- 3) Determine header mounting height = X. See below.
- 4) Bolt header to the wall with appropriate hardware.
- 5) Locate and mount door arm slide track onto the door at 4" from C/L of pivot, mounting holes 5/8" from top of the door as shown below.
- 6) Insert shaft/ drive arm into the operator, **leave shaft bolt loose until appropriate step during commissioning procedure.**
- 7) Proceed to page 16 to perform commissioning.

Standard Aluminum Arm




X: Mounting height (distance bottom of header to top of door)


Part No.	Shaft Length	X
141032 (STD)	3-7/32" [82mm]	1-3/4" [44mm]
141205	4-27/32" [123mm]	3-3/8" [86mm]
141020	2-5/8" [67mm]	1-5/32" [29mm]

For extended reveals contact TORMAX

Stainless Steel Arm



Butt Hinge or Offset Pivot



Inswing (Pull) Arm 0" Reveal Commissioning



Requirements

1. Shaft should be loose in the drive unit. Drive arm connected to slide track and shaft.
2. Determine system values for your application based on the illustrations on page 10.

Commissioning



Commissioning Example: (3) = 36" door width, (1) = 0-2" reveal, (1) = Standard inswing Arm 11 3/8.



Press & Hold Programming Button, **Release** after **1 Green LED** Flash. The operator will make 1 beep and immediately begin to flash the **Yellow LED**.

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 1X, then after **3 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 2X, then after **1 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 3X, then after **4 yellow flashes**, **Press & Release** Programming Button

MADE AN ERROR DON'T WORRY: To start over Disconnect Power for 10 seconds, Reconnect Power, then **Press & Hold** Programming Button and **Release** after **5 Green LED** Flashes.

The operator will open 20 degrees stop and beep 2x. Attach Door Arm to Slide Track and Shaft, place the Door in the Closed Position, and **NOW** Tighten the shaft to the operator at 25 ft-lbs. REMOVE POWER from Operator and adjust open door stop to desired position, refer to page 22 for adjusting internal Open Door Stop.

RECONNECT POWER (operator beeps 1x), then **Press & Hold** programming button & **Release** after **6 Green LED** Flashes. The operator will open 20 degrees stop and beep 2x. **Press & Release** programming button. Operator will slowly close and beep 2x, next slowly fully open & beep 2x, then close (beep 1x) followed by 5 beeps, and will cycle fully open & close at normal speed.


Commissioning is complete for High Energy Applications. For Low Energy application complete the last step below Program the country code into the controller. For additional programming refer to page 23 or Programming Tables.

Enter Country Code 7 1: (Read Entire Step BEFORE attempting to enter Country Code)



PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.

Press & Hold programming button, **Release** after **7 Green** flashes then immediately **Press & Release** programming button after **1 Yellow** flash.

Inswing (Pull) Arm 0 - 6" Reveal Installation



- 1) Determine the handing of the operator according to the door. Note that arrow on operator indicates opening direction of rotation.
- 2) Locate & mark output shaft location as shown below from CL of hinge or pivot onto door frame.
- 3) Mark header mounting height of 1 1/8" from the top of the door as shown below.
- 4) Secure header to the wall with appropriate hardware.
- 5) Locate and mount door arm slide track onto the door at 3 3/4" from bottom of the header and at the dimensions listed below for the application.
- 6) Insert shaft/ drive arm into the operator, **leave shaft bolt loose until appropriate step during commissioning procedure.**
- 7) Proceed to page 18 to perform commissioning.



Inswing (Pull) Arm 0 - 6" Reveal Commissioning




Requirements

1. **Shaft should be loose in the drive unit. Drive arm connected to door and shaft.**
2. Determine system values for your application based on the illustrations on page 10.

Commissioning



Commissioning Example: (3) = 36" door width, (1) = 2-4" reveal, (1) = Extended inswing Arm B.



Press & Hold Programming Button, **Release** after **1 Green LED** Flash. The operator will make 1 beep and immediately begin to flash the **Yellow LED**.

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 1X, then after **3 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 2X, then after **2 yellow flashes**, **Press & Release** Programming Button

PAUSE

WHILE LOOKING AT THE YELLOW LED, WAIT FOR THE OPERATOR TO BEEP 3X, then after **6 yellow flashes**, **Press & Release** Programming Button

MADE AN ERROR DON'T WORRY: To start over Disconnect Power for 10 seconds, Reconnect Power, then **Press & Hold** Programming Button and **Release** after **5 Green LED** Flashes.

The operator will open 20 degrees stop and beep 2x. Attach Door Arm to Slide Track and Shaft, place the Door in the Closed Position, and **NOW** Tighten the shaft to the operator at 25 ft-lbs. REMOVE POWER from Operator and adjust open door stop to desired position, refer to page 22 for adjusting internal Open Door Stop.

RECONNECT POWER (operator beeps 1x), then **Press & Hold** programming button & **Release** after **6 Green LED** Flashes. The operator will open 20 degrees stop and beep 2x. **Press & Release** programming button. Operator will slowly close and beep 2x, next slowly fully open & beep 2x, then close (beep 1x) followed by 5 beeps, and will cycle fully open & close at normal speed.


Commissioning is complete for High Energy Applications. For Low Energy application complete the last step below Program the country code into the controller. For additional programming refer to page 23 or Programming Tables.

Enter Country Code 7 1: (Read Entire Step BEFORE attempting to enter Country Code)

PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.


Press & Hold programming button, **Release** after **7 Green** flashes then immediately **Press & Release** programming button after **1 Yellow** flash.

Double Egress Application Installation




- 1) Determine the handing of the operators according to the door. Note that arrow on operator indicates opening direction of rotation.
- 2) Locate & mark output shaft locations as shown above, for both operators.
- 3) Determine header mounting height. If both operators are in a single header then mount the operators at $1-1/8''$ from top of the door as shown below for In-Swing operator.
- 4) Secure header to the wall with appropriate hardware.
- 5) Locate and mount door arm and slide track onto the doors at dimensions listed above.
- 6) Insert shaft/ drive arms into the operators, **leave shaft bolts loose until appropriate step during commissioning procedure.**
- 7) Proceed to page 20 to check or connect sync cable and additional wiring.

In-Swing Operator



Out-Swing Operator




Pair & Double Egress Application Wiring

1. Determine which operator will be the primary drive as this will have the 3-position switch connection.


! The FCP is an option in place of the 3-position and will be connected to the primary drive with appropriate module, Exterior Door module EDM or Programming Interface module PIM.

2. Check and/ or install jumpers between GND pin 1 - IN1 pin 2 and GND pin 1 - IN2 Pin 3 in place of the 3-position switch on the secondary drive as shown below.


Primary Drive



Secondary Drive




3. Install Multi Door Module MDM-B into each operator.



4. Connect Sync cable (US801886) to both drives Multi Door Module MDM - B as shown below.

Wiring of Sync Cable



! Do not apply primary power to the drive units until the appropriate step.

Proceed to page 21.

Pair & Double Egress Application Commissioning


Requirements for Both Operator

1. An MDM module Installed in both operators along with optional modules (PIM, EDM, PDM) prior to start-up. Refer to Technical Specifications section.
2. Refer to application's commissioning page to determine shaft condition. (loose or secured)
3. Determine system values based on the illustrations on page 10.



Commissioning


1. Connect primary power 120vAC to **Primary operator first**, then the Secondary operator this will configure the operators (Primary/ Secondary).




2. Commissioning sequence - **Perform Commissioning of Primary operator first**, then perform Commissioning of Secondary operator.

3. Refer to the applications Commissioning page:


Outswing 8-10 lbs. Spring Holding force (Low Energy) -
Refer to page 11 for securing the Shaft & Arm position,
Page 12 for commissioning




Outswing 14- 15 lbs. Spring Holding Force (Full Power) - Page14



Inswing 0" Reveal - Page 16



Inswing 0-6" Reveal - Page 18



4. Adjustments:


Double egress/ simultaneous pairs - Turn OFF delayed activation of secondary operator = Code 830

Frequently used adjustments are listed on page 23

Adjustments - Door Stop/ 1201 Spring Tension

Adjusting Internal Open Door Stop


Determine opening angle required for application adjust internal stop accordingly.



⚠ An external door stop may be needed depending on application (abuse, excessive wind...).

Mechanical Spring Tension Adjustment (Optional) - **1201 ONLY**

⚠ Adjust spring tension to close the door in adverse applications with no primary power applied.



- Adjust spring tension on the operator, note Code for the adjustment made.
Example 20mm = Code 5.

	0	5	10	15	20	25	30	35	40	Tension length in mm
Number of Flashes	1 *	2	3	4	5	6	7	8	9	Code

- Programming spring tension adjustment with On-Board Button:
(Read Entire Step BEFORE attempting to enter Country Code)

PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.

Press & Hold programming button, **Release** after **4 Green** flashes then immediately **Press & Release** programming button after **# Yellow** flashes for **code value** .

- Changing the spring tension will require a commissioning process to be performed with On-Board button Code 6 Green flashes or entering Code 021 with FCP.

Adjustments - Frequently Used

Adjustments

Country Code configures the operator for Low Energy application for more details refer to page 31. To set the Country code 7 with On-Board Button follow the instructions below:

Enter Country Code 7 1: (Read Entire Step BEFORE attempting to enter Country Code)

PERFORM THIS STEP WHILE LOOKING AT BOTH GREEN & YELLOW LEDS.

Press & Hold programming button, **Release** after **7 Green** flashes then immediately **Press & Release** programming button after **1 Yellow** flash.

Additional adjustments may be made after commissioning which require a PIM Program Interface module and an FCP. If the door requires or is equipped with an EDM Exterior Door Module then a PIM is not needed.

Listed below are the most common adjustments. For a complete list of adjustments refer to the Programming Charts.

- *Hold open time = Code 10?
- *Push-N-Go OFF = Code 860
- *Close Check Force OFF = Code 320
- **Power Close for Lock Release ON = Code 581
- **Delay Time to Open = Code 591
 - Power Pulse when Opening = Code 43? *Over come wind stack pressure or lock*
- *Double egress/ simultaneous pairs = Code 830
 - Turn OFF delayed activation of secondary operator for pair applications.*

Detecting/ mask out safety functions details on page 31:

- On-Board Button = Code 3
- FCP = Code 023

Repeat commissioning without system values details on page 31.

- On-Board Button = Code 6

- Power Assist in AUTO ON = Code 862
- Power Assist Hold open Time = Code 150


- * Adjustments have been changed by entering Country code 7.
- ** Adjustment 591 needs to be made in conjunction with 581.

Testing



Test the door in accordance with ANSI A156.19 Power Assist and Low Energy Power Operated Doors or ANSI A156.10 Power Operated Pedestrian Doors standards before putting the door into service and handing it over to the End-User.

Slim Line - Header Preparation



Slim Line - Application Illustrations

REVISIONS		DATE	APPROVED
REV	DESCRIPTION		
A	Final Issue	4/27/2016	MH

<p>14 - 15 lbs. Spring Holding Force</p> <p>Commissioning and programming page 14.</p>	<p>Inswing 0" - 6" Reveal</p> <p>Commissioning and programming page 16.</p>	<p>Double Egress Pair</p>
<p>8 - 10 lbs. Spring Holding Force</p> <p>Commissioning and programming page 12.</p>	<p>Inswing 0" - 6" Reveal</p> <p>Commissioning and programming page 18.</p>	<p>Double Egress Pair</p>

Reference 1102/1201 Installation and Operating manual for commissioning and programming instructions for specific applications listed.

Application Wiring page 20, commissioning and programming page 21.

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TORMAX USA. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TORMAX USA IS PROHIBITED.


Description: 1102 / 1201 Slim Line Swing Door Applications	Drawing Number: Revision 1102-1201 Header Fabrication Sheet
Drawn By: Maro Hagera	Date: 5/11/2016

SHEET 2 OF 2

Programming with the FCP - Overview



Programming with the Functional Control Panel (FCP) refer to T1757 in Technical Specification section requires at least one of the following modules to be installed PIM shown below refer to T1691 or EDM T1638.




The Functional Control Panel (FCP) has 2 function levels:

Level 1 - End user

- Select operating modes
- Display three-digit fault codes.
- Access protected eliminates unauthorized programming.

Level 2 - AAADM Certified Technician


- "U" = User readable parameter - allows technician to read specific parameters. See programming chart for parameters.
- Access protection, access code (111)
- Programming door system to comply with the current ANSI A156.10 or ANSI A156.19 standard.
- Displays currently set parameter.
- 10 min time out after the last programming entry is made. The technician will be required to enter the access code (111) to make further adjustments.





Programming with the FCP - Overview

- ! Button 1 - Changes the number or letter by increments of one (0, 1, 2, 3 - 9, a, b, c, ... back to 0)
- ! Button 2 - Confirms/ enter displayed number or letter into the control.



1) Start Access Code



2) Entering Access Code 111



3) Start Programming Level




4) Entering Parameter Code 103


- ! If a number is entered incorrectly, stop and let the process time out. (no change made)

Programming with the FCP


Example 1: Enter access code **111**





Example 2: Enter code **103** to adjust the Hold Open time for 2 sec



Hold Open time for Automatic 1 is now set for 2 sec

- 

Within 10 minutes you can enter the programming mode by pressing both keys simultaneously and P will display. If no further adjustments are made after 10 minutes the FCP will time out and require access code re-entry. **Repeat example 1.**
- 

After confirming/ entering the 2nd number of the code, the 3rd flashing value (number or letter) of the code is the parameter setting. If the value is confirmed the FCP will rapidly flash for 1 sec then display "P" again.
- 

Quickly pressing and releasing both buttons simultaneously the FCP will return to displaying the mode of operation.

Commissioning with FCP


Requirements:

1. Programming with the Functional Control Panel (FCP) requires at least one of the following modules to be installed PIM refer to T1691 or EDM T1638. If optional modules (MDM, PDM) are required install prior to start-up.
2. The drive arm is connected to the door and the drive arm shaft has not been tightened, **exception outswing 8 - 10 lbs** .
3. Pair of doors - the sync cable and additional wiring outlined on page 20 has been completed.
4. Connect safety sensors to door control, adjust in accordance to manufacturer's specifications.

Start-up:

⚠ Double egress/ simultaneous pairs applying power in the wrong sequence will cause configuration problems.

1. Apply primary power to the operator, for pair of doors apply power to the Primary operator first, then to the Secondary operator.



2. Enter System Parameters - Refer to page 10 to determine values. Complete sequence for Primary operator first.



Enter **Code 06?** Door width


Enter **Code 07?** Distance of drive arm

Enter **Code 08?** Sliding lever length

3. Arm Preload

Enter **Code 021** operator will rotate 20 degrees, with the door arm connected to the door, place the door in the closed position, tighten shaft retaining bolt to 25 ft.lbs.


Remove primary power plug from operator, door will close.



4. For pair applications - repeat process for secondary operator beginning at step 2.

5. Adjusting Open door stop

Determine opening angle required for application adjust internal stop accordingly.




⚠ An external door stop may be needed depending on application (abuse, excessive wind).

Proceed to page 30

Commissioning with FCP

Commissioning

1. Apply primary power to the operator, for pair of doors apply power to the Primary operator first, then to the Secondary operator.




2. Commissioning - Enter **Code 021** Start commissioning, for pairs complete primary operator sequence first.

3. Door will automatically open and hold open at 20 degrees. 2 Audible Tones

4. Exit Preload - Enter **Code 020** door closes.

5. Door will automatically begin opening until the open door stop is reached, door will immediately close. (Checking door weight/ momentum)



6. Escalating 6 tones will occur before door begins opening. (Door mounted safety sensor inhibiting)



7. For pair applications, repeat sequence for secondary operator, begin at step 2. Primary operator will go to the open position until commissioning is completed.

Additional Adjustments

Additional adjustments may need to be made after commissioning. Listed below are the most common adjustments. For additional adjustments refer to the Programming Charts.

*Hold open time = Code 10?

*Push-N-Go OFF = Code 860

*Close Check Force OFF = Code 320

**Power Close for Lock Release ON = Code 581

**Delay Time to Open = Code 591

Power Pulse when Opening = Code 43? *Over come wind stack pressure*

*Double egress/ simultaneous pairs = Code 830

Turn OFF delayed activation of secondary operator for pair applications.

Detecting/ mask out safety functions details on page 31 = Code 023

Power Assist in AUTO ON = Code 862

Power Assist Hold open Time = Code 150

Repeat commissioning without system values details on page 31.

On-Board Button = Code 6

* Adjustments have been changed by entering Country code 7.

** Adjustment 591 needs to be made in conjunction with 581.

Testing



Test the door in accordance with ANSI A156.19 Power Assist and Low Energy Power Operated Doors or ANSI A156.10 Power Operated Pedestrian Doors standards before putting the door into service and handing it over to the End-User.

Code Descriptions/ BDM LED Displays

Country Code

The Country code is available in firmware V3.02 and above. The country code provides preset values to aid the technician in installing the door to comply with ANSI Standard A156.19. Country code can be set with On-board button Code 7/1 or FCP code 031. To remove the country code adjustments perform a factory reset. Functions changed are listed below:

Hold Open Time=105	Opening Speed=203	Closing Speed=214
Closing Force=311	Close Check Force=320	Safety Function BDM IN4=602
Safety Function PDM IN4=651	Pair without Overlap=830	Push N Go OFF=860

Detecting safety features (optional)

If the safety sensors in the opening and/or closing direction were not detected correctly or have been connected for the first time, they can be subsequently detected. Detect and save safety features 1–2

Code 3 on-board configuration (FCP code = 023)

Procedure according to Code 023 or OB Code 3	Conditions	Result
<p>Waiting time 5 seconds (rising motor signal tone). The safety sensor connection type is detected. The door opens and closes again.</p> <p>After the door reaches the open position, the number of testable safety sensors is indicated by the number of times the green LED (0–2 times).</p>	<p>Sensors must be correctly connected. Do not enter the detection area of the moving safety sensors.</p>	<p>If the testing of the safety feature “open” is successful, the door opens at full power. If the testing of the safety feature “close” is successful, the door closes at full power. The safety feature “open” is automatically suppressed if the door moves against a wall.</p>

Repeat commissioning (without system values)

If the door arm or shaft position was changed or glass was installed in the door after commissioning.

Code 6 on-board configuration

Procedure according to OB Code 6	Conditions	Result
<p>Operator rotates 20°, beeps 2x, Press & Release the OB button, operator will close slowly, automatically opens slowly & fully open & beeps 2X, close (beep 1x) followed by 5 beeps. and will fully open & close at normal speed.</p>	<p>Door travel path un-obstructed, no physical contact with the door during the learn cycles. Minimal wind load.</p>	<p>Door open & closed positions detected. Door weight detected. Safety functions detection according to Code 023, OB Code 3.</p>

Displays

Troubleshooting codes displays as E / H on the user interface. See the Troubleshooting Codes Chart in this manual for their meaning.

LED displays on the base door module BDM

Yellow LED off	OK
Yellow LED on	Error (E). See the user interface or Skipper for the error display. See the Trouble shooting chart in this manual.
Green LED on	Power supply and module OK
Green LED off	No power supply or power supply overloaded.
Green LED flashes	A programming step was started via the on-board programming button. The process is on going. Press the button briefly to stop the process.
The Green LED flashes after the open position is reached	0 × = No testable safety feature available. Door moves with low energy. 1 × = 1 testable safety feature available. Door moves with low energy. 2 × = 2 testable safety features available. Door moves with full energy.

Programming Table

Code	Function	Note
01 1	UR Door operator type 1102	Remains after factory reset
01 2	UR Door operator type 1201	Remains after factory reset
02 0	End procedure "Spring preload"	
02 1	Start commissioning	Only possible after entering system parameters 06x, 07x, 08x
02 2	Start Teach-In	
02 3	Detecting and storing of safety functions	Safety functions on terminals in3+4 PDM" and in4 BDM
02 4	Delete registration of unplugged modules MDM, PDM, EDM	The modules will be registered automatically at power-up
03 1	Preset 1=Handicap Function (=OB code 7/1) (=P105,203,214,311,320,602,651,830,860,870)	Reverse with factory reset
04 0	UR Reset	Starts program with calibration run
04 1	Factory Reset	All adjustments back to default values (see *)
04 2	UR Display firmware version	Example: r06_00 = V06.00
04 3	UR Display number of cycles	Example: c10_302 = 10'302 cycles (max. 9979997999)
04 4	UR Display number of operating hours	Example: h4_002 = 4002 hours (max.99'999'999)
04 5	Delete fault protocol	
05 0	Display registration module EDM	A0 =not registered, A1 =registered
05 1	Display registration module PDM	A0 =not registered, A1 =registered
05 2	Display registration module MDM	A0 =not registered, A1 =MDM-A registered, A2 =MDM-B registered
05 3	Display registration secondary door operator	A0 =Single door, A1 =primary door, A2 =secondary door
05 4	Display voltage intermediate circuit 40VDC	Example: u22_8 = 22,8V
05 5	Display voltage 24VDC supply	Example: u22_8 = 22,8V
05 8	Display temperature transformer (calculated) (from FW V03.10)	Example: t39_5 = 39,5 degree C
05 9	Display temperature motor (calculated) (from FW V03.10)	Example: t39_5 = 39,5 degree C
06 1..8	Door width (=OB code 1/1)	
	0* 1 2 3 4 5 6 7 8	code
	0 28" 32" 36" 40" 44" 48" 52" 56"	inches
07 1..6	Reveal (=OB code 1/2)	
	0* 1 2 3 4 5 6	code
	0 1-2" 2-4" 4-6" 6-8.5" 8.5-10.5" 10.5-12.5"	inches
08 1..6	Drive Arm Length (=OB code 1/3)	
	0* 1 2 3 4 5 6	code
	0 11-3/8" Custom 13-3/4" 13-3/4" Custom Custom	inches (Out-Swing Arm/ Push 1,2,3) (In-Swing Arm/ Pull 4,5,6)
09 0..9	Spring tension (=OB code 4) ONLY APPLIES to 1201 Operator	
	1* 2 3 4 5 6 7 8 9	
	0 5 10 15 20 25 30 35 40	mm
10 0..F	UP Hold-open time for Auto Mode	Is also determined by the teach-in.
	0 1* 2 3 4 5 6 7 8 9 A b C d E F	code
	0 1 2 3 4 5 6 7 8 9 10 15 20 40 60 >/>	sec. (>/>=step control)
11 0..F	UP Hold-open time of activator for Beds	
	0 1 2 3 4 5 6 7 8* 9 A b C d E F	code
	0 1 2 3 4 5 6 7 8 9 10 15 20 40 60 >/>	sec. (>/>=step control)
12 0..F	UP Key Switch Hold-open time	
	0 1 2 3* 4 5 6 7 8 9 A b C d E F	code
	0 1 2 3 4 5 6 7 8 9 10 15 20 40 60 >/>	sec. (>/>=step control)
13 0..9	UP Delay time Mode of op. OFF	
	0 1 2* 3 4 5 6 7 8 9	code
	1 3 5 7.5 10 15 20 30 45 60	sec.
14 0..9	UP out3 EDM: Bell active time	0 = Off
	0 1 2* 3 4 5 6 7 8 9	code
	0 0.5 1 2 3 4 5 6 8 10	sec.
15 0..9	Power Assist Hold- open time after opening	0 = Off
	0 1* 2 3 4 5 6 7 8 9 A b C d E F	code
	0 1 2 3 4 5 6 8 10 12.5 15 17.5 20 40 60 >/>	sec.

UP=(P) Program mode. UR=(R) Read parameter mode

* = Default value

Programming Table

Code	Function	Note
20	0...9	UP Opening speed
	0 1 2 3 4 5 6* 7 8 9	Code
	10 25 40 55 70 85 100 110 120 130	%
21	0...9	UP Closing speed
	0 1 2 3 4 5 6* 7 8 9	Code
	10 25 40 55 70 85 100 110 120 130	%
22	0...9	Close check speed
	0* 1 2 3 4 5 6 7 8 9	Low Energy max 67N / F (+0 to -30%) code
	2 5 8 11 14 17 20 23 26 30	N (no= no limit)
30	1...9	UP Motor force opening
	1 2 3 4 5 6* 7 8 9	Low Energy max 67N / F (+0 to -30%) code
	40 55 67 80 95 120 150 175 no	N (no= no limit)
31	0...9	UP Motor force closing
	0 1 2 3 4 5 6* 7 8 9	Low energy max 67N / F (+0-30%) / S= only force of spring code
	S 40 55 67 80 95 120 150 175 no	N (no = no limit)
32	0...8	UP Motor force at close check
	0 1 2 3 4 5 6* 7 8	Low energy max 67N / F (+0-30%) / S= only force of spring code
	S 40 55 67 80 95 120 150 175	N (max)
33	0...6	Motor holding closed force (New commissioning required! >H14)
	0 1 2 3* 4 5 6	% of the set spring force. code
	-90 -60 -30 0 +30 +60 +90	%
34	1...5	Power Assist closing force after opening
	0* 1 2 3 4 5	Force on door edge code
	S 5 10 15 20 25	N (S=Spring force)
35	0...9	Reversing time obstacle opening
	0 1 2 3 4 5 6* 7 8 9	code
	5 4.5 4 3.5 3 2.5 2 1.5 1 0.5	sec.
36	0...9	Reversing time obstacle closing
	0 1 2 3 4 5 6* 7 8 9	code
	5 4.5 4 3.5 3 2.5 2 1.5 1 0.5	sec.
37	1...5	Power Assist opening resistance
	0 1 2 3* 4	code
	5 10 15 20 25	N
38	0...6	UP Push-and-Go/ Power Assist start angle
	0 1 2 3* 4 5 6	code
	1 2 3 5 8 12 16	degree
39	0...5	UP Push-and-Close start angle
	0 1 2 3 4 5*	0 = 5 degrees before the closed position code
	- 8 10 12 14 16	degree
40	0...9	Correction open position
	0 1 2 3 4* 5 6 7 8 9	Stop = open against endstop (not if H17 is displayed) code
	95 97 98 99 100 101 102 103 105 Stop	%
41	1...9	Advance angle for unlocking
	1 2 3 4 5 6 7* 8 9	Valid only from FW V02.10 code
	1 1.5 2 2.5 3 3.5 4 4.5 5	degree
42	0...9	Angle for close & open check
	0* 1 2 3 4 5 6 7 8 9	Note the context of the parameters P22x, P32x, P42x code
	0 1 1.5 2 2.5 3 3.5 4 4.5 5	degree
43	0*...3	Power pulse when opening
		0 = off, 3 = maximum

UP=(P) Program mode. UR=(R) Read parameter mode

* = Default value

Programming Table

Code	Function	Note
50 0	No switch off safety sensors	
50 1	Switch off safety sensors in: P	Connect power of sensor to GNDct (PDM)
50 2 *	Switch off safety sensors in: P, OFF if door closed >60s, OPEN >60s	Connect power of sensor to GNDct (PDM)
51 0	No switch off activator sensors	
51 1	Switch off sensor in: P	Connect power of sensor to GNDct (EDM)
51 2 *	Switch off sensor in: P, OFF if door closed, OPEN	Connect power of sensor to GNDct (EDM)
51 3	Switch off sensor in: P, OFF and EXIT if door closed, OPEN	Connect power of sensor to GNDct (EDM)
52 0	No switch off of LED on User Interface USIN-7	
52 1 *	Switch off LEDs on user interface USIN-7 1 min. after use	LEDs switch on when needed
55 0	Locks in operating mode OFF	When using electric. strikes: 100% duty ratio required
55 1	Locks in operating mode OFF, EXIT	When using electric. strikes: 100% duty ratio required
55 2	Locks in operating mode OFF, AUTO, EXIT	When using electric. strikes: 100% duty ratio required
55 3 *	Locks in operating mode OFF, AUTO, EXIT, P	
56 0 *	out2 EDM: Without holding magnet function	
56 1	out2 EDM: Holding magnet active in closed position	
56 2	out2 EDM: Holding magnet active in open position	
57 0 *	out1B EDM: Electric strike: current-free locked - fail secure	
57 1	out1B EDM: Electric strike/ Maglock: current-free unlocked - fail safe	Only for electric strike with 100% duty ratio
57 2	out1B EDM: No lock	
57 3	out1B EDM: Motorised lock	With return signal: Programm P59A or B
58 0 *	No power close for electric strike release	
58 1	Power close for electric strike release	Requires min. unlocking time of 0,2s (P591)
59 0...b	Delay time to open (or until response "R" for motorised lock)	Only valid if electric strike has to unlock
	0 * 1 2 3 4 5 6 7 8 9 A b	code
	0,1 0,2 0,4 0,8 1,2 1,6 2 2,5 3 4 R/NO R/NC	sec. / Response
60 0	in4 BDM: No function	Safety functions use only once with 60x, 64x, 65x!
60 1 *	in4 BDM: Safety swing area	Contact type NO, NC detect with code P023 or OB 3
60 2	in4 BDM: Safety closing with reversing function	Contact type NO, NC detect with code P023 or OB 3
60 3	in4 BDM: Safety closing with creeping function	Contact type NO, NC detect with code P023 or OB 3
60 4	in4 BDM: Safety opening with stop function	Contact type NO, NC detect with code P023 or OB 3
60 5	in4 BDM: Safety opening with creeping function	Contact type NO, NC detect with code P023 or OB 3
60 6	in4 BDM: Power-assistance pre-triggering	Function depending of op. mode and P85x-87x, x>=2
61 0	out1 BDM: No function	
61 1 *	out1 BDM: Message "General fault"	
61 3	out1 BDM: Message "door closed"	
61 4	out1 BDM: Message "door closed and locked"	Only with response of motorised lock
61 5	out1 BDM: Message "door open"	
61 6	out1 BDM: Message "Mode of operation OFF"	
62 0 *	in1 PDM: No function	
62 1	in1 PDM: Emergency closing	Contact type NC
62 2	in1 PDM: Emergency opening	Contact type NC
64 0 *	in3 PDM: Safety opening with stop function	Contact type NC+test, NC, NO detect with P023 or OB 3
64 1	in3 PDM: Safety opening with function "Low-Energy"	Contact type NC+test, NC, NO detect with P023 or OB 3
64 2	in3 PDM: Safety stop	Contact type NC+test, NC, NO detect with P023 or OB 3
64 3	in3 PDM: Safety swing area	Contact type NC+test, NC, NO detect with P023 or OB 3
65 0 *	in4 PDM: Safety closing with reversing function	Contact type NC+test, NC, NO detect with P023 or OB 3
65 1	in4 PDM: Safety closing with function "Low-Energy"	Contact type NC+test, NC, NO detect with P023 or OB 3
65 2	in4 PDM: Safety stop	Contact type NC+test, NC, NO detect with P023 or OB 3
65 3	in4 PDM: Safety swing area	Contact type NC+test, NC, NO detect with P023 or OB 3

UP=(P) Program mode. UR=(R) Read parameter mode

* = Default value

Programming Table

Code	Function	Note
70 0 *	out1 MDM: Message "door open"	MDM- A (Non Stocking part, special order)
70 1	out1 MDM: Battery in service	MDM- A (Non Stocking part, special order)
71 0 *	out2 MDM: Message "door closed"	MDM- A (Non Stocking part, special order)
72 0 *	out3 MDM: Message "door closed and locked"	MDM- A (Non Stocking part, special order)
72 1	out3 MDM: Message "General fault"	MDM- A (Non Stocking part, special order)
73 0 *	out4 MDM: Door ready for operation	MDM- A (Non Stocking part, special order)
73 1	out4 MDM: Mode of operation OFF	MDM- A (Non Stocking part, special order)
74 0	in1 MDM: no function	MDM- A (Non Stocking part, special order)
74 1 *	in1 MDM: Mode of operation OFF	MDM- A (Non Stocking part, special order)
75 0	in2 MDM: no function	MDM- A (Non Stocking part, special order)
75 1 *	in2 MDM: Mode of operation OPEN	MDM- A (Non Stocking part, special order)
76 0	in3 MDM: no function	MDM- A (Non Stocking part, special order)
76 1 *	in3 MDM: Mode of operation EXIT	MDM- A (Non Stocking part, special order)
77 0	in4 MDM: no function	MDM- A (Non Stocking part, special order)
77 1 *	in4 MDM: Passage for beds	MDM- A (Non Stocking part, special order)
77 2	in4 MDM: Operation mode MANUAL	MDM- A (Non Stocking part, special order)
80 0 *	UP out3 EDM: Bell trigger: Activator outside	
80 1	UP out3 EDM: Bell trigger: Activator inside	
80 2	UP out3 EDM: Bell trigger: Key switch	
81 0..4	UP Button pressed time for handicapped	Valid for inside/outside and key switch activations
	0 * 1 2 3 4	code
	0 1 2 3 5	sec.
82 0 *	Emergency operation in case of faulty safety > for low risk	At E31-36: Creep speed with force <67N
82 1	Safety operation in case of faulty safety > for high risk	At E31-36: Manual operation
83 0	Double wing door without overlapping, synchronous	Application see T-1763, T1753
83 1 *	Double wing door with overlapping	Application see T-1763, T1753
83 2	Double wing door with "Door coordinator device" MDC	Application see T-1763, T1753
84 0 *	Battery switches off after 10s	
84 1	Battery operation in all modes of operation	
84 2	Battery operation in AUTO, EXIT, OPEN	In all other modes, the battery switches off after 10s
84 3	Opens with battery in OFF, AUTO, EXIT, OPEN	In all other modes, the battery switches off after 10s
84 4	Opens with battery in AUTO, EXIT, OPEN	In all other modes, the battery switches off after 10s
85 0 *	No opening assistance in MANUAL	
85 2	Power-assistance in MANUAL incl. pre-trigger by activator in-/outside	+ Triggered by angle or in4 BDM (in4 only with P510)
85 3	Power-assistance in MANUAL	Triggered by angle or pre-release by IN4 BDM
86 0	No opening assistance in AUTO	
86 1 *	Push & Go in AUTO	
86 2	Power-assistance in AUTO	Triggered by angle or pre-release by IN4 BDM
87 0	No opening assistance in EXIT	
87 1 *	Push & Go in EXIT	
87 2	Power-assistance in EXIT	Triggered by angle or pre-release by IN4 BDM
90 0 *	Programming button (BDM) released	
90 1	Programming button (BDM) disabled	
91 0..4	UP Access code lock for control unit	0 = off
	0 * 1 2 3 4	code
	-- 111 222 333 123	code
92 0 *	User parameter enabled	
92 1	User parameter disabled	

UP=(P) Program mode. UR=(R) Read parameter mode

* = Default value

Troubleshooting Codes

* E = Error | H = Hint


* No.	Fault	Behaviour of System	Reset
E0x	Internal test negative. Fatal error.	Safety operating	Power OFF-ON. Possibly press button 5s
E11	Motorised lock not unlocked	Door blocked	Automatically if OK
E12	Motorised lock not locked		Automatically if OK
E23	CAN connection EDM interrupted	Safety operating mode	
E24	CAN connection PDM interrupted	Safety operating mode	
E25	CAN connection MDM interrupted	Safety operating mode	
E26	CAN connection primary - second. interrupted	Primary continues, second. stays closed	
E31	Safety open > 1 min. active, test neg.	According safety function	Automatically if OK
E32	Safety closing > 1 min. active, test neg.	According safety function	Automatically if OK
E33	Safety stop > 1 min. active, test neg.	According safety function	Automatically if OK
E34	Safety swing area > 1 min. active, test neg.	According safety function	Automatically if OK
E35	Safety open creep > 1 min. active, test neg.	According safety function	Automatically if OK
E36	Safety close creep > 1 min. active, test neg.	According safety function	Automatically if OK
E37	Safety open Low En. > 1min. active, test neg.	According safety function	Automatically if OK
E38	Safety clos. Low En. >1min. active, test neg.	According safety function	Automatically if OK
E41	Activator inside > 1min. active	Door remains open	Automatically if OK
E42	Activator outside > 1min. active	Door remains open	Automatically if OK
E43	Key switch > 1min. active	Door remains open	Automatically if OK
E45	Emergency open > 1 min. active	Door remains open	Automatically if OK
E46	Emergency close > 1 min. active	Door closes and remains closed	Automatically if OK.
E47	Inhibit switch > 1 min. active	Door closes without hold open time	Automatically if OK.
E48	Activator bed passage > 1min. active	Door remains open	Automatically if OK
E51	Encoder not working	Safety operating mode	Reset
E61	Power supply 40V outside of admissible range	Safety operating mode	Automatically if OK
E62	Power Supply 24V outside of permissible range	Safety op. mode	Automatically if OK
E63	Power Supply 24V short circuit	Safety op. mode	Automatically after 20s if OK
E64	Motor hot	Safety operating mode	Automatically after cooling down
E66	Motor faulty. Interruption of motor control.	Safety operating mode. No braking!	Replace motor
E68	Power failure (Power on)		
E99	Error at secondary drive unit		
H01	System was started	Safety op. mode	Reset
H02	Factory reset required (VEE unreadable)	Safety mode	Factory reset
H11	Parameter 06... not yet programmed	Safety operation	Enter parameter
H12	Parameter 07... not yet programmed	Safety operation	Enter parameter
H13	Parameter 08... not yet programmed	Safety operation	Enter parameter
H14	Commissioning not executed	Safety operation	Start commissioning
H15	Timeout moving. Door blocked. Motor faulty	Commissioning is canceled	Restart commissioning
H16	Mass detection faulty (wind, opening angle)	Autom. detection is terminated	Restart automatic detection
H17	Open endstop too soft. Motor may overheat		
H18	Safety function is used more than once		See P60x, P64x, P65x
H19	Detection of safety functions pending		P023 or OB code 3
H21	Teach-In: Door moves >25 s before start	Abort Teach-In	New Teach-In
H22	Teach-In: No start within 60s	Abort Teach-In	New Teach-In
H23	Teach-In: Movement to slow. >60 s	Abort Teach-In	New Teach-In
H31	Obstacle detection at opening	Door reverses	Automatically, Display 20s.
H32	Obstacle detected at closing	Door reverses	Automatically, Display 20s.
H33	Permanent obstacle at opening	Safety operation	Reset
H34	Permanent obstacle at closing	Safety operation	Reset
H46	FW mismatch in primary and secondary		
H62	Calibration run in closing direction	Searches closed position	At the end of movement
H67	Absolute position not found yet	Slow opening movement	
H71	Battery mode	Door moves slowly	Power supply return
H74	Motor current in open position too high	E64 can trigger later	P404. Avoid wind load. Install HM

Control Connection Diagram



Connect components only with primary power removed (current-less).


Terminal Allocation in Default Programming



1) Function programmable
 2) OUT 1A & OUT 1B are Normally Open dry contact
 Load on power supply 24 VDC max. 1.5 A/36 W

Connection Diagram

1102/ 1201 Basic Board (BDM)




NOTE:

- 1) Enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing speeds, forces, turns Push n Go function OFF and sets Hold Open time to 5 seconds.
- 2) To make additional adjustments an FCP - Functional Control Panel will be needed.
- 3) Adjust operator to be in accordance with ANSI A156.19
- 4) Refer to Larco Ultra-Small Receiver Installation Guide for proper setup and adjustments.

TORMAX USA Inc.	
<i>12859 Wetmore Rd. San Antonio, Tx 78247</i>	
Title: 1201/ 1102 Single with Larco 433 Activation	
Drawn by: Jerry Morgan	Revised by: GDM
Date: 8/29/17	Revision #: 02
Drawing #: 1201002	

Connection Diagram

1102/ 1201 Basic Board (BDM)




NOTE:

- 1) Enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing speeds, forces, turns n Go function OFF and sets Hold Open time to 5 seconds.
- 2) To make additional adjustments an FCP - Functional Control Panel will be needed.
- 3) Adjust operator in accordance with ANSI A156.19.

TORMAX USA Inc.	
12859 Wetmore Rd. San Antonio, Tx 78247	
Title: 1201 / 1102 LE Single with hard wired push plates	
Drawn by: Jerry Morgan	
Date: 8/29/17	Revised by: GDM
Drawing #: 1201001	Revision #: 02

Connection Diagram




NOTE:

- 1) Determine which door mounted sensor is being installed reference wiring connections listed to the right .
- 2) Enter Code 602 to program IN4 for Safety Closing with Reversing Function.
- 3) Adjust operator and sensors to be in accordance with ANSI A156.19.
- 4) Refer to manufacturers Installation/ Users guides to setup and adjust the OA - EDGE, SuperScan, and Larco Receiver.

TORMAX USA Inc.	
12859 Wetmore Rd, San Antonio, TX 78247	
Title: 1201 / 1102 Single LE with Door Mounted Sensor on Push Side Larco Receiver FW 3.00	
Drawn by: Jerry Morgan	Revised by: GDM
Date: 8/29/17	Revision #: 02
Drawing #: 1201008	

Connection Diagram




POWER DOOR MODULE TERMINALS C5 C6 C7 C8

OA - EDGE (PUSH SIDE)	BROWN	7
OR	YELLOW	6
SUPERSCAN (PUSH SIDE)	GREEN	5
	WHITE	8

POWER DOOR MODULE TERMINALS C1 C2 C3 C4

OA - EDGE (PULL SIDE)	BROWN	7
OR	PINK	6
SUPERSCAN (PULL SIDE)	BLUE	5
	WHITE	8



- NOTE:**
- 1) Do not enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing forces.
 - 2) Reference wiring connections listed to the right for door mounted sensor being installed.
 - 3) If installing an OA-EDGE sensor on both sides of the door the Brown & White wires will be connected to pins C1 & C4 only.
 - 4) The OA-EDGE monitoring settings should be Dipswitch A7=OFF, A8=OFF, B3=ON.
 - 5) Adjust operator and sensors to be in accordance with ANSI A156.10.
 - 6) Refer to manufacturers Installation/ Users guides to setup and adjust the OA - Edge, SuperScan, Eagle and/ or Larco Receiver.

TORMAX USA Inc.
 12859 Wetmore Rd. San Antonio, Tx 78247

Title: 1201 / 1102 Single with Door Mounted Sensors,
 Larco Receiver, Eagle, FW 3.00

Drawn by: Jerry Morgan


Date: 8/16/17

Drawing #: 1201007

Revised by: GDM

Revision #: 02


Connection Diagram



- NOTE:**
- 1) Do not enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening/ closing speeds and forces.
 - 2) Install jumper into PDM C terminal pin 6,7 as shown above for power assist close functionality.
 - 3) Adjust operator and sensors to be in accordance with ANSI A156.10.
- Refer to manufacturers Installation/ Users guides to setup and adjust the LZR Microscan, Eagle and/ or Larco Receiver.

TORMAX USA Inc.	
<i>12859 Wetmore Rd San Antonio, TX 78247</i>	
Title: FE 1201 / 1102 Single with LZR Microscan Sensors, Larco Receiver, Eagle, FW 3.00	
Drawn by: Jerry Morgan	Revised by:
Date: 8/22/17	Revision #:
Drawing #: 1201013	

Connection Diagram



- NOTE:
- 1) Enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing speeds, forces, turns Push n Go function OFF and sets Hold Open time to 5 seconds.
 - 2) To make additional adjustments an FCP - Functional Control Panel will be needed.
 - 3) Adjust operators to be in accordance with ANSI A156.19
 - 4) Sync cable has a 120 ohm resistor at both ends.
 - 5) Jumpers must be connected to Secondary operator A Terminals 1 to 2, 1 to 3.

TORMAX USA Inc.

12859 Wetmore Rd. San Antonio, Tx 78247


Title: 1201/ 1102 LE Pair with Hard Wired Push Plates

Drawn by: Jerry Morgan

Date: 8/29/17 Revised by: GDM

Drawing #: 1201003 Revision #: 02

Connection Diagram




- NOTE:**
- 1) Enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing speeds, forces, turns Push n Go function OFF and sets Hold Open time to 5 seconds.
 - 2) To make additional adjustments an FCP - Functional Control Panel will be needed.
 - 3) Adjust operators to be in accordance with ANSI A156.19
 - 4) Sync cable has a 120 ohm resistor at both ends.
 - 5) Refer to Larco Ultra-Small Receiver Installation Guide for proper setup and adjustments.

TORMAX USA Inc.
 12859 Wetmore Rd. San Antonio, Tx 78247

Title: 1201 / 1102 LE Pair with Larco 433 Receiver
 Activation, Optional Jamb Switch

Drawn by: Jerry Morgan	Revised by: GDM
Date: 8/30/17	Revision #: 02
Drawing #: 1201004	





Connection Diagram



- NOTE:**
- 1) Determine which door mounted sensor is being installed reference wiring connections listed to the right.
 - 2) Reference 1201/1102 Installation & Service manual for details of dual operator installation and commissioning.
 - 3) Enter Code 602 to program IN4 for Safety Closing with Reversing Function.
 - 4) Adjust operator and sensors to be in accordance with ANSI A156.19.
 - 5) Refer to manufacturers Installation/ Users guides to setup and adjust the OA - EDGE, SuperScan and Larco Receiver.


TORMAX USA Inc.	
12859 Wetmore Rd, San Antonio, TX 78247	
Title: 1201 / 1102 Pair LE with Door Mounted Sensors Push Side, Larco Receiver FW 3.00	
Drawn by: Jerry Morgan	Revised by: GDM
Date: 8/29/17	Revision #: 02
Drawing #: 1201009	

Connection Diagram



NOTE:

- 1) Do not enter the Country Code (OBC=7/1) or (FCP=031) as this will limit/ reduce your opening and closing forces.
- 2) Reference wiring connections listed to the right for door mounted sensor being installed.
- 3) If installing an OA-EDGE sensor on both sides of the door the Brown & White wires will be connected to pins C1 & C4 only.
- 4) The OA-EDGE monitoring settings should be Dipswitch A7=OFF, A8=OFF, B3=ON.
- 5) Adjust operator and sensors to be in accordance with ANSI A156.10.
- 6) Refer to manufacturers Installation/ Users guides to setup and adjust the OA - Edge, SuperScan, Eagle and/ or Larco Receiver.




TORMAX USA Inc.
12859 Wetmore Rd, San Antonio, Tx 78247

Title: 1201 / 1102 Pair with Door Mounted Sensors, Larco Receiver, Eagle, FW 3.00

Drawn by: Jerry Morgan
Date: 8/16/17
Revised by: GDM

Drawing #: 1201006
Revision #: 02

Connection Diagram



TECHNICAL SPECIFICATIONS



100009	Mechanical Documentation Shaft Removal	★★★★★ TORMAX AUTOMATIC 12859 Wetmore Road San Antonio, TX 78247 1-888-685-3707 WWW.TORMAXUSA.COM
Area of application	iMotion 1301, 1201, 1102 Swing Door Operator	
Release	August 2016	
Use	Technician Reference	

Purpose

Provide guidance in the removal of the drive arm shaft for a 1301,1201, 1102 operator. Removal of the shaft will require the extraction bolt part# US801643.


Removal

1. Remove power from the operator, remove the arm assembly from the shaft.
2. Remove the shaft retaining bolt part# US801528 as shown in illustration #1.
3. Insert the shaft extraction bolt into the operator & shaft as shown in illustration #2
4. Using a 6 mm hex head allen wrench turn the bolt in a clockwise direction, screwing in the extraction bolt. The bolt pushes the shaft out of the operator as shown in illustration #3.



TECHNICAL SPECIFICATIONS

T1253e Cable Plan



No.	Control Components	Notes	Cable	Length (ft) without screen	Length (ft) with screen
1	Activator/Push-button inside	Stranded wire recommended	4 × 20 AWG	< 98	< 328
2	Activator/Push-button outside	Stranded wire recommended	4 × 20 AWG	< 98	< 328
3	Key-switch	Stranded wire recommended	2 × 20 AWG	< 98	< 328
4	Input	Stranded wire recommended	... × 20 AWG		< 328
5	User interface iMotion Connected with FCC-connector		Phone ribbon cable 6 × 014 mm ² RJ12,6P,6C	< 98	
	User interface iMotion Connected with LIN-Adapter		3 × 025 mm ²	< 98	< 100
6	Safety activator closing		4 × 20 AWG	< 98	< 328
7	Safety activator opening	Stranded wire recommended	4 × 20 AWG	< 98	< 328
8					
9	Door lock	Stranded wire recommended	4 × 20 AWG	< 82	< 328
10	Message 1 ...	Stranded wire recommended	2 × 20 AWG	< 98	< 328
11	Message 2 ...	Stranded wire recommended	2 × 20 AWG	< 98	< 328
12	Mains main switch		3 × 14 AWG		

TECHNICAL SPECIFICATIONS

T-1633e 1201 Technical Information

Drive type	TORMAX 1201 Swing Door Drive
Drive system	Electro-mechanical drive with DC-motor, extensible with modules, spring activated closing or opening.
Control System	MCU42
Door leaf width and mass	28" – 56", up to 551 lbs. according to diagram




Opening angle	70° ... 110° max.
Speed	5° ... 60°/s max.
Mains connection	230/115 VAC, 50/60 Hz
Dimensions	3-11/32" x 5-3/64" x 25-13/64" 2 leaves with mechanical door coordinator: 100 x 135 x door width
Power consumption	3 ... 200 W
Automatic reset in the event of a power failure	In the closing and opening direction; capable of an infinitely variable setting: 60–100 % of maximum force according to DIN 1154 corresponds to closer parameter 4-6 with the linkage pushing and closer parameter 3 when the linkage is pulling.
Protective class	IP 20
Ambient temperature	–68 ... 122° F
Weight:	26 lbs
Emitted noise level	< 70 dBA
Sensor supply	24 VDC (+0.5–1.5 V) Pmax. 36 W, I _{max.} 1.5 A
Inputs	24 VDC or potential-free (Multi Door Module MDM-A)
Outputs	Holding magnet 24 VDC, <0.25 A (Exterior Door Module EDM) Bell 24 VDC, <1 A, (Exterior Door Module EDM) El. door opener 24 VDC, <1 A, (Exterior Door Module EDM) Potential-free 24 VDC, <1 A, (Multi Door Module MDM-A) Test-out 24 VDC, <1 A, (Power Door Module PDM)
Interfaces	CAN for double door and air lock (MDM-A/MDM-B) RS232 for Skipper (EDM, Programming Interface Module PIM) RS485 (MDM-A) LIN-Bus (EDM, Programming Interface Module PIM))
Approvals and standards	CE EN 16005 (TÜV) UL 325 UL 228 EN 61000-6-2, EN 61000-6-3, EN 60335-1
Durability	DIN 18650 (TÜV) – 1 Million test cycles at 4000 cycles per day

TECHNICAL SPECIFICATIONS

T-1634e 1102 Technical Information

Drive type	TORMAX 1102 Swing Door Drive
Drive system	Electro-mechanical drive with DC-motor, extensible with modules, spring activated closing or opening.
Control System	MCU42
Door leaf width and mass	28" – 48", up to 275 lbs. according to diagram



Opening angle	70° ... 110° max.
Speed	5° ... 60°/s max.
Mains connection	230/115 VAC, 50/60 Hz
Dimensions	3-11/32" x 5-3/64" x 25-13/64" 2 leaves with mechanical door coordinator: 100 x 135 x door width
Power consumption	3 ... 140 W
Automatic reset in the event of a power failure	In the closing and opening direction corresponds according to DIN 1154 to closer parameter 4 with the linkage pushing.
Protective class	IP 20
Ambient temperature	-68... 122° F
Weight:	11,2 kg
Emitted noise level	< 70 dBA
Sensor supply	24 VDC (+0,5–1,5 V) Pmax. 36 W, I _{max} . 1,5 A
Inputs	24 VDC or potential-free (Multi Door Module MDM-A)
Outputs	Holding magnet 24 VDC, <0,25 A (Exterior Door Module EDM) Bell 24 VDC, <1 A, (Exterior Door Module EDM) El. door opener 24 VDC, <1 A, (Exterior Door Module EDM) Potential-free 24 VDC, <1 A, (Multi Door Module MDM-A) Test-out 24 VDC, <1 A, (Power Door Module PDM)
Interfaces	CAN for double door and air lock (MDM-A/MDM-B) RS232 for Skipper (EDM, Programming Interface Module PIM) RS485 (MDM-A) LIN-Bus (EDM, Programming Interface Module PIM)
Approvals and standards	CE EN 16005 (TÜV) UL 325 EN 61000-6-2, EN 61000-6-3, EN 60335-1
Durability	DIN 18650 (TÜV) – 1 Million test cycles at 4000 cycles per day

TECHNICAL SPECIFICATIONS

Electrical Requirements for Installation Personnel

Have a licensed electrician:


- Make all mains primary power connections in accordance to federal, state and local regulations.
- Route mains primary power from power distribution panel (10 amp circuit breaker minimum per operator) to the operator.
- Install a service switch or emergency shut OFF switch, if required by customer or per regulations. This is in addition to the mains circuit breaker to interrupt power, switch must be rated @ 10 amp minimum.

Mains Connection

Connection: N + L1 + PE protected on site with 10 AT, protective earth necessary

Power rating: 1 x 230 / 1 x 115 V AC (+5 %/ – 10 %) 50– 60 Hz, max. 200 W

Supply cable: Type H05VV-F, H05RR-F or flexible cord of type S, SO, SJ, SJO, ST, STO, SJT, SJTO or AFS




T1132/1



Before beginning the work described below, check that the mains primary power is switched off. If required place “Out of Service” tag on circuit breaker or service switch.

- Route the mains connection to the operator along the side of the power supply.
- The edges must be rounded off on all bushings for the mains connection.
- Route mains cable either through the header end cap or through header back plate.
- Use only cable bushings made from synthetic materials Metallic bushings must be grounded.
- Connect mains cable to terminal (1) as shown in the illustration.



- Secure mains cable with a cable strap at a synthetic lug on the base plate.
- Do not apply power to the door until ready for commissioning.
- A system switch (FCP or 3-position switch) must be on site.



Secure mains cable properly to prevent it from getting into the moving parts of the operator or door system.


TECHNICAL SPECIFICATIONS

T-1753 e	Application Double Door Hospital	<p style="text-align: center;">★★★★★ TORMAX AUTOMATIC</p> <p>12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com</p>
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	10 October 2014	
Use	Planning, installation, maintenance	

Purpose

The purpose of the application is to coordinate double-leaved doors using Type 1201 or 1102 swing door drives with each other in such a manner that non-overlapping double doors open at the same time as each other and that overlapping double doors open with a brief time interval between each leaf and close in the right order. Fire doors may only be operated with the proven mechanical door coordinator system MDC.

Function



Door Opening Sequence

Movement without overlapping (P830). Synchronous

When an opening command is given both door leaves start to open at the same time. The door leaves move independently of each other according to a pre-set motional sequence.

At the end of the hold-open time on the primary leaf (commences as soon as both door leaves have reached the open position), both leaves begin to close independently of each other according to a pre-set motional sequence.

Reverse commands are transmitted to both drives. However, an obstruction on opening only affects the door leaf encountering the obstruction.

Movement with overlapping (P831, P832). Asynchronous

When an opening command is given the primary leaf starts to open. When an opening angle of 7 degrees is reached, the secondary leaf starts to open. The door leaves move independently of each other according to a pre-set motional sequence.

At the end of the hold-open time on the primary leaf (commences as soon as both door leaves have reached the open position) both leaves begin to close independently of each other according to a pre-set motional sequence.

The primary leaf then stands still at an angle of 10 degrees / 40 degrees (P831, P832) and waits in this position until the secondary leaf is completely closed. The primary leaf does not close until the secondary leaf is completely closed.

Reverse commands are transmitted to both drives.


Operating Mode Control and Operation

The operating modes and the reset function are entered on the primary drive. These then apply automatically for both drives. Single leaf operation is entered on the secondary leaf.

TECHNICAL SPECIFICATIONS

Connection

See T-1688 for cable diagram for double-leaf system



TECHNICAL SPECIFICATIONS

T-1637 e	Module Documentation Base Door Module MCU42-BDM-A	<p style="text-align: center;">★★★★★ TORMAX AUTOMATIC</p> <p>12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com</p>
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	22 December 2014	
Use	Planning, installation, maintenance	


Purpose

Central control component for the TORMAX 1102 and 1201 swing door drives.

Function

The base door module (BDM) provides all the essential basic functions for the operation of a swing door system (see also installation overview T-1660). Additional functions and interfaces can be added with the additional modules (EDM, PDM, MDM). The BDM and additional modules communicate with each other via the internal CAN-BUS. The BDM is able to recognize the additional modules automatically via the CAN-BUS after their connection and then to initialize/configure them appropriately.

Base Module MCU42-BDM-A




- 1 Motor connection
- 2 Power supply module
- 3 Connector plugs for additional modules
- 4 Terminal A for 3 position switch, internal activator, programmable IN4 and OUT1
- 5 Push button SW1 for configuration or opening impulse (push twice)
- 6 Orange LED for error display or configuration
- 7 Green LED for status display (ready for operation) or configuration

Installation




If the module is touched it must be protected against electrostatic discharge (ESD). Other components must not be touched.

- Only connect the basic module (8) and secure it to the points provided when the power is switched off.
- Do not switch on the power until any additional MCU4 modules (10) which are required are connected.
- Place the cover plate (9) in position.




- 1 Base door module BDM
- 2 Cover plate
- 3 Additional modules EDM, PDM, MDM, PIM



TECHNICAL SPECIFICATIONS

Module Connections

The additional modules EDM, PDM, MDM may be arranged in any order. The programming interface module PIM can be connected at the end of the row. Standard assignment for terminal connections - see T-1655.



T1637_2e

Commissioning

The system may be configured either by means of the on-board configuration tool (SW1 and LEDs) or the MCU32-USIN-7 user interface or iMotion Skipper software.

iMotion Skipper is used for firmware updates (see TORMAX Extranet). Firmware updates install the latest software versions on the modules which are connected.

Programming using the user interface - see T-1248.

Technical Data

Processor:	32 bit, 100 MHz
System monitoring:	Complies with the requirements of DIN 18650
Ambient temperature:	- 4 ... +122 °F
Over temperature protection:	+167 °F
Dimensions:	2.519" × 3.858"
Output OUT 1:	max. load 1 amp (at 68 °F) Thermal overload protection, self resetting
Inputs IN 1 - 4:	24 VDC / 3mA pull up
Serial interfaces:	1 x CAN (internal) 1 x LIN (connection only via EDM or PIM) 1 x RS485 (connection only via MDM) 1 x RS232 (connection only via EDM or PIM)
Module interfaces:	MCU42-EDM-A (T-1638) MCU42-PDM-A (T-1639) MCU42-MDM-A (T-1640) MCU42-MDM-B (T-1640) MCU42-PIM-A (T-1691)

TECHNICAL SPECIFICATIONS

T-1638 e	Module Documentation Exterior Door Module MCU42-EDM-A	<p>★★★★★ TORMAX AUTOMATIC</p> <p>12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com</p>
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	9 January 2015	
Use	Planning, installation, maintenance	


Purpose

Additional module for the TORMAX 1102 and 1201 Swing Door Drive for external doors.

Function

The exterior door module (EDM) contains all connections needed for an external door. The inputs and outputs which supplement the BDM are not programmable.

External door module MCU42-EDM-A




- 1 Connector plugs for additional modules
- 2 Inputs (IGA: external activator, SS: key switch)
- 3 Outputs (OUT2: holding magnet, OUT3: bell)
- 4 Output OUT1 potential-free (door opener, motor lock),
Input IN1 (motor lock feed-back)
- 5 RS232 (Skipper)
- 6 LIN (user interface)
- 7 Status display

Installation



The module must be protected against electrostatic discharge (ESD) when touching it. Other components must not be touched.


- Only plug in the module and secure it to the points provided when the power is switched off.



TECHNICAL SPECIFICATIONS

Module Connections

The additional modules EDM, PDM, MDM may be arranged in any order. Standard assignment for terminal connections see T-1655.



Commissioning

The module is automatically recognized by the basic module BDM as soon as the power is switched on. The LED status display is illuminated when the module is ready for operation.

Technical Data

Processor:	32 bit, 100 MHz
System monitoring:	Complies with the requirements of DIN 18650
Ambient temperature:	- 4 ... +122 °F
Dimensions:	2.519" × 2.519"
Outputs OUT 2-3:	max. load 1 A (at 68 °F) Thermal overland protection, self resetting
Outputs OUT 1 A/B:	Potential-free max. load 1 A (at 68 °F) Thermal overland protection, self resetting Voltage max. 40 VDC/ 30 VAC Potential relative to earth max. 75 VDC/ 50 VAC
GNDct:	max. load 1 A (at 68 °F) Thermal overload protection, self resetting
Inputs IN 1/SS/IGA:	24 VDC/ 3mA. pull up
Serial interfaces:	1 x CAN (internal)
Module interfaces:	1 x LIN 1 x RS232 (Skipper) MCU42-BDM-A (T-1637) MCU42-PDM-A (T-1639) MCU42-MDM-A (T-1640) MCU42-MDM-B (T-1640)

TECHNICAL SPECIFICATIONS


T-1640 e	Module Documentation Multi Door Module MCU42-MDM-A /B	<p>★★★★★ TORMAX AUTOMATIC</p> <p>12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com</p>
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	9 January 2015	
Use	Planning, installation, maintenance	

Purpose

Additional module for the TORMAX 1102 and 1201 swing door drives for operating double leaved doors or air locks. The module is also used for networking via RS485 or if additional potential-free inputs and outputs become necessary.

Function

In the case of double doors and/or air locks, communication between the drives is via the CAN-BUS on the MDM.




Installation



If the module is touched it must be protected against electrostatic discharge (ESD). Other components must not be touched.


- Only connect the module and secure it to the points provided when the power is switched off.



TECHNICAL SPECIFICATIONS


Module Connections

The additional modules EDM, PDM, MDM may be arranged in any order. Standard assignment for terminal connections see T-1655.




T1637_2e


Potential-free inputs




Circuit diagram



Potential-free outputs



Circuit diagram




Commissioning

The module is automatically recognised by the basic module BDM as soon as the power is switched on. The LED status display is illuminated when the module is ready for operation.

Technical Data

Processor:	32 bit, 100 MHz
System monitoring:	Complies with the requirements of DIN 18650
Ambient temperature:	-4 ... +122 °F
Dimensions:	2.519" × 2.519"
CAN ext.:	CAN open, 125 kbit/s, 500 m in a line (max. 22 m from transmission line)
RS485:	For details see T-1531 (RS485-network)
Outputs OUT 1-4 A/B:	Potential-free, max. load 1 A (at -4 °F), Thermal overload protection, self resetting Voltage max. 40 VDC / 30 VAC, Potential relative to earth max. 24 VDC/ 50VAC
Inputs IN 1-2:	24 VDC / 3 mA Pull up, Potential-free, Signal source 10-30 VDC
Inputs IN 3-4 A/B:	Potential relative to earth max. 75 VDC/ 50 VAC
Module interfaces:	MCU42-BDM-A (T-1637) MCU42-EDM-A (T-1638) MCU42-PDM-A (T-1639) MCU42-PIM-A (T-1691)

TECHNICAL SPECIFICATIONS

T-1639 e	Module Documentation Power Door Module MCU42-PDM-A	 12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	7 January 2015	
Use	Planning, installation, maintenance	


Purpose

Additional module for the TORMAX 1102 and 1201 swing door drive for full energy operation.

Function

Two testable safety features can be connected to the PDM. If a testable safety feature is recognised when the door is opening, the door is automatically opened at full power. If a testable safety feature is recognised in the closing direction, the door is automatically closed at full power. The door moves at low power if there are no testable working safety features.

Power Module MCU42-PDM-A



1 Additional module connecting plug

2 Inputs

- IN1: emergency movement
- IN2: inhibit switch

3 Testable safety features

- OUT2 / IN4: S2 safety, opening
- OUT1 / IN3: S1 safety, closing


4 Status display

Installation



If the module is touched it must be protected against electrostatic discharge (ESD). Other components must not be touched.


- Only plug in the module and secure it to the points provided when the power is switched off.



TECHNICAL SPECIFICATIONS

Module Connections

The additional modules EDM, PDM, MDM may be arranged in any order. Standard assignment for terminal connections see T-1655.



Commissioning

The module is automatically recognised by the basic module BDM as soon as the power is switched on. The LED status display is illuminated when the module is ready for operation.

Technical Data

Processor:	32 bit, 100 MHz
System monitoring:	Complies with the requirements of DIN 18650
Ambient temperature:	- 4 ... +122 °F
Dimensions:	2.519" × 2.519"
Outputs OUT 2-3:	max. load 1 A (at -4 °F) Thermal overload protection, self resetting
GNDct:	max. load 1 A (at -4 °F) Thermal overload protection, self resetting
Inputs IN 1-4:	24 VDC/ 3 mA Pull up
Module interfaces:	MCU42-BDM-A (T-1637) MCU42-EDM-A (T-1638) MCU42-MDM-A (T-1640) MCU42-MDM-B (T-1640) MCU42-PIM-A (T-1691)

TECHNICAL SPECIFICATIONS



T-1691 e	Module Documentation Programming Interface Module MCU42-PIM-A	<p>★★★★★ TORMAX AUTOMATIC</p> <p>12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com</p>
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	17 July 2014	
Use	Planning, installation, maintenance	

Purpose

Additional module for the TORMAX 1102 and 1201 Swing Door Drive for programming with iMotion Skipper or with the user interface USIN-7-A.

Function

The module is only temporarily used for programming with iMotion skipper. The module is only required if there is no exterior door module EDM installed. At the EDM the required RS232 interface is available.



- 1 Programming Interface Module MCU42-PIM-A
- 2 RS232 (Skipper)
- 3 LIN (user interface)
- 4 Securing screws
- 5 Connector plug


Installation

- Plug in the module in current-free state to the base module BDM or the last installed module respectively by means of the connector plug (5).
- Lock the module with securing screws (4).

Technical Data

Dimensions:	2.519" × 2.519"
Serial interfaces:	1 x LIN 1 x RS232 (Skipper)
Module interfaces:	MCU42-BDM-A (T-1637) MCU42-PDM-A (T-1639) MCU42-MDM-A (T-1640) MCU42-MDM-B (T-1640)

TECHNICAL SPECIFICATIONS



T-1757 e	Module Documentation User interface MCU32-USIN-7-A	 12859 Wetmore Road San Antonio, Tx 78247 1-888-685-3707 www.tormaxusa.com
Area of application	TORMAX 1102, 1201 Swing Door Drive	
Release	15 August 2014	
Use	Planning, installation, maintenance	

Purpose

Operation and programming of automatic doors with MCU32 and MCU42 Swing Door Drives.


Function

Code switch



Connection Diagram

User interface



TECHNICAL SPECIFICATIONS

Installation

Mounting Frame


Switch on primary power at the operator after the user interface is connected.

- Mount the FCP user interface in the appropriate holder box system.
- Or mount FCP in the side cover.


LIN Connection

Cut to length and assemble the LIN connection cable on both ends with a FCC 6-pole plug. The polarity of the FCC-plug is not of importance.

For alternative cable connections via adapter with terminal connection see module documentation LIN-Bus adapter T-1322.



Component Dimensions



Technical Data

Inputs:	2 x Pull up in: 24 VDC/ 3mA, function programmable
Terminal cross section:	20 AWG (stranded wire)
LIN interface:	FCC 6-Pol
Length of all LIN cables:	< 328'
LIN cable length between modules:	< 98' max, phone ribbon cable 6 x 0.14 mm ² < 100' max, LIN-Bus-Adapter MCU32-LADP-A
Ambient temperature:	- 4 ...+122 °F
Dimensions:	1.7716" × 1.7716", recess min. .787"
Module interface	MCU42-EDM-A MCU42-PIM-A (for commissioning and maintenance) MCU32



Your First Choice for Automatic Doors

TORMAX Sliding Doors

TORMAX Swing Doors

Sales, Installation and Service.
Automatic and Manual Doors

TORMAX USA Inc.

12859 Wetmore Road
San Antonio, TX 78247
888-685-3707
www.tormaxusa.com

TORMAX is a Division and a registered trademark of Landert Motoren AG