



ICU grounding & interlock.


3.025d3 04/07/05



ICU GROUNDING ASSEMBLY




C2076-3 ICU INTERLOCK BUMPERS

For field installation 4 assemblies required
Exterior view



C3190 ICU POSITIVE LATCH

For parts replacement only




C460 ICU FLUSH BOLT

For "SO" panel of trackless ICU




Series 310 smoke rated ICU



3.0019d 08/08/05





"SX" latch assembly for smoke rated and standard ICU doors (trackless or track models)




This assembly is NOT a direct replacement
for C3190 ICU positive latch
-A new strike rail is required
-Jamb prep for the keeper










NOTE:
C4196 harness is ONLY used on
SIMULTANEOUS OPERATORS.
The power supply harness C3959-4
and C4192 are used instead of C3959-1
on pairs.










For pairs header prep for
 closer is the same each end











DISCONTINUED
6/05



DISCONTINUED
6/05

C12163
Accessory bag
(6)C417




DISCONTINUED

6/05

Arm assemblies for swing door applications


4.023d9 01/10/04



DIRECT DRIVE for FOLDING & SWING DOORS

Arm assemblies swing door & folding applications


4.041d9 05/31/05

C5686Connection for
1/2" glass**C5686-1**Connection for
3/4" glassC5254-1 is
required when
ordering one of
these connections
note: discard the
foot and mounting
screws**C5254-1
CONNECTING ARM
ASSEMBLY**C3080-14
14 tooth (in)
60 tooth (out)C3080-48
48 tooth (in)
60 tooth (out)**C4250-14 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**

For 14 tooth output shaft and 60 tooth arm

**C4250-48 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**




For 48 tooth output shaft and 60 tooth arm

C4193-1
60 toothC3080-14
14 tooth (in)
60 tooth (out)C3080-48
48 tooth (in)
60 tooth (out)**C4252-14 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**

For 14 tooth output shaft and 60 tooth arm

**C4252-48 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**


For 48 tooth output shaft and 60 tooth arm

C4195-1
60 toothC4193-3
14 tooth**C4250-1 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY****C4252-1 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**C4195-4
14 tooth**EXTENDED SWING DOOR ARMS**C3080-14
14 tooth (in)
60 tooth (out)C3080-48
48 tooth (in)
60 tooth (out)**C4236-14 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**

For 14 tooth output shaft and 60 tooth arm

**C4236-48 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**



For 48 tooth output shaft and 60 tooth arm


C3080-14
14 tooth (in)
60 tooth (out)C3080-48
48 tooth (in)
60 tooth (out)**C4238-14 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**

For 14 tooth output shaft and 60 tooth arm


**C4238-48 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**

For 48 tooth output shaft and 60 tooth arm


**C5254-3
EXTENDED CONNECTING ARM
ASSEMBLY**




C4548-1
4000 side load temporary pivot




C4538-1
4000 bottom load temporary pivot




C9538-1
7000 side load temporary pivot







SWING DOOR
NON THRESHOLD PIVOT






SWING DOOR
THRESHOLD PIVOT




SWING DOOR
THRESHOLD PIVOT w/ MATS




FOLDING DOOR with 1/4" JAMBS & 1/2" THRESHOLD
or DIRECT DRIVE SWING DOOR




FOLDING DOOR or DIRECT DRIVE SWING DOOR
NON THRESHOLD



C9527-1 A/B breakaway with switch for isolated pivot or direct drive




C4517-1 A/B fixed stop for bottom load header with isolated pivot




C4517-2 A/B fixed stop for side load header with isolated pivot

Bifold top roller, hinges, pull handle & breakout assembly

7.080d 11/98




Top roller guide for inactive panel




Pull handle


See section L11.0 & L11.3 for swing arm & bottom pivot.




C7700-1 LHR hinge assembly for LHR & RH units





C7702-1 RHR hinge assembly for RHR & LH units



C7618 Bifold breakout assembly for pair units (half shown) C7619 & C7620 similar.








HORTON ILLUSTRATED PARTS LIST


Series 8000 single slide window

L13.02
8.037d1 11/98




Series 8000 self close window

8.052d2 11/98





After June 2001




Motor and gear drive for automatic and security revolving doors


9.302d 5/01










4-Wing pivot assemblies







4-Wing magnetic breakout assembly






Replacement weather strip assemblies:









Standard revolver collector and brushes

FOR UNITS BUILT BEFORE 2001
See page L14.0 for current parts


Grand revolver collector and brushes

FOR UNITS BUILT BEFORE 2004
See page L14.11 for current parts



C9419-2/B/Q/S Lock indicator assembly

C9373-1 Coupling assembly

Reed switch and top pivot assembly for Grand

C9371 Grand bottom center pivot bearing




HORTON ILLUSTRATED PARTS LIST
Series 9500 standard mechanical speed control

L14.08
9.239d2 1/01

**OLD VERSION
SEE L14.8 (9.239d4
or higher)**






FOR UNITS BUILT
BEFORE 2004

HORTON ILLUSTRATED PARTS LIST


Bookfold for manual doors


L14.10


9.307d2 3/22/02



FOR UNITS BUILT 2004 OR LATER







All glass revolver wings and center section

