

CONDOR



UNIVERSAL SLIDE CONTROLLER

CONDOR


"Quick Harness"

Wiring Diagram for Stanley DuraGlide (new style interface board)

MOTIONACCESS, LLC
automatic entrance solutions

MotionAccess, LLC
775 Nicholas Blvd.
Elk Grove Village, IL 60007
toll free: 866-357-8832
847-357-8832, fax: 847-357-8834
www.MotionAccess.com

Connect to the existing harness (from the interface board).



BLACK
VIOLET
ORANGE
YELLOW

Terminal Block Detail

A	Digital Comm.	1	Dig. Pwr - 5Vdc
B	common	2	common
C	Thres. Sensor	3	SideLite / Misc 1
D	common	4	common
E	Breakaway	5	Security / Misc 2
F	common	6	common
G	Beams / Safety	7	Reduced Open
H	common	8	common
I	Exterior Activate	9	Sel. Switch 1
J	common	10	common
K	Interior Activate	11	Sel. Switch 2
L	common	12	Sel. Switch 3

FOR TECHNICAL ASSISTANCE CALL 866-357-8832

MA70415_QHW_revA1