

MC 521 **BLACK LABEL PRO** SETUP FOR **DUAL LOW ENERGY**

Power **ON**

Turn Mode selector switch to **CLOSED** or **OFF**

*****Remember when releasing enter you only have 2 seconds to make a change*****

A) Hold enter and press down to **#99**

Release enter, press down one time to **#00**

B) Hold enter and press down to **#96**

Release enter, press up one time to **#01**

You will then see "A0" on display

C) Hold enter and press up to **#00**

Release enter, press up to until you see **#08**

You will then see "A0" on display

D) Hold enter and press up to **#01** (motor 01)

Release enter, go to "**00**" for right hand or "**01**" for left hand

You will then see "A0" on display

E) Hold enter and press up to **#02** (motor 02)

Release enter, go to "**00**" for right hand or "**01**" for left hand

You will then see "A0" on display

F) Hold enter and press up to **#03**

Release enter, press **UP** one time

You will see "20" briefly, then "A1" on display

G) Hold enter and press up to **#11**

As long as you don't have sentrex, release enter and change it to **#00**

You will see "A1" on display

H) With the doors in the **fully closed position**, you will now flip your mode switch to **HOLD OPEN**. **AS SOON AS THE DOOR BEGINS TO MOVE, FLIP THE MODE SWITCH BACK TO CLOSED/OFF**. The door will now go thru a "learn" process. This consists of the door opening and closing several times until you see "A2" on the display. Once "A2" is present you will:

I) Hold enter and press down to **#99**

Release enter, press **up** one time to "**01**"

It will then read "20" briefly, then go to "00"

At this point you may put your switch to **AUTOMATIC** and run your door.

Need additional help? Contact us at 1-800-222-9601 for Tech Support!